

Battery

Battery	Computer
GB-AC1	Aspire One series Acer Aspire One ZG5 (Linux) Acer Aspire One A110 Series Gateway LT 11.6" Series Gateway LT1000, Gateway LT1001, Gateway LT1001G, Gateway LT1001J, Gateway LT1004, Gateway LT1004U, Gateway LT1005, Gateway LT-1005C, Gateway LT1005U, Gateway
GB-AC1	Aspire One series Acer Aspire One ZG5 (Linux) Acer Aspire One A110 Series Gateway LT 11.6" Series Gateway LT1000, Gateway LT1001, Gateway LT1001G, Gateway LT1001J, Gateway LT1004, Gateway LT1004U, Gateway LT1005, Gateway LT-1005C, Gateway LT1005U, Gateway
GB-AC100	TravelMate C100/C102/C104/C110/C111/C112 Series
GB-AC1300	Acer Aspire 1300DXV Aspire 1300Series Aspire 1300XC Aspire 1300XV Aspire 1301XV Aspire 1302LC Aspire 1302X Aspire 1302XC Aspire 1304LC Aspire 1304XC Aspire 1306LC Aspire 1307LC Aspire 1310LC Aspire 1310 Series Aspire 1310XC Aspire 1312LC Aspire 1312LM Asp
GB-AC1350	Aspire 1350/1510 series/1350, 1350LC, 1350LCe, 1350LM, 1350LMi, 1351, 1351LC, 1351LCi, 1351XC, 1352, 1352LC, 1352LCe, 1352LCi, 1352XC, 1353, 1353LC, 1353LCi, 1353LM, 1353LMi, 1353XC, 1354, 1354LM, 1354LMi, 1355, 1355LC, 1355LCe, 1355LCi, 1355LM, 1355LMi,
GB-AC1350H	Aspire 1350/1510 series/1350, 1350LC, 1350LCe, 1350LM, 1350LMi, 1351, 1351LC, 1351LCi, 1351XC, 1352, 1352LC, 1352LCe, 1352LCi, 1352XC, 1353, 1353LC, 1353LCi, 1353LM, 1353LMi, 1353XC, 1354, 1354LM, 1354LMi, 1355, 1355LC, 1355LCe, 1355LCi, 1355LM, 1355LMi,
GB-AC1360	Aspire 1360/1362/1520/1521/1610/1612/1620/1620LC/1660/1661/3010/5010/5012WLMi/ 2000/2001LC/2500/2501FLC/240/242FX(MS2138)/250/ 250LCi/ 2000/ 2001FX/2500/ 2500LCAcer Aspire 1360 /1520/1610/ 1620/1660/3010/5010/ Extensa 2000/2500/TravelMate 240/250/2000/250
GB-AC1360H	Aspire 1360/1362/1520/1521/1610/1612/1620/1620LC/1660/1661/3010/5010/5012WLMi/ 2000/2001LC/2500/2501FLC/240/242FX(MS2138)/250/ 250LCi/ 2000/ 2001FX/2500/ 2500LCAcer Aspire 1360 /1520/1610/ 1620/1660/3010/5010/ Extensa 2000/2500/TravelMate 240/250/2000/250
GB-AC1400	Acer Aspire 1400 Amilo D6800, Amilo D7820, Amilo D8800, Amilo D8820
	FUJITSU

Battery

GB-AC1410	Aspire 1410-2039 Aspire 1410-2099 Aspire 1410-2285 Aspire 1410-2497 Aspire 1410-2706 Aspire 1410-2762 Aspire 1410-2801 Aspire 1410-2920 Aspire 1410-2936 Aspire 1410-2954 Aspire 1410-2990 Aspire 1410-8414 Aspire 1410-8804 Aspire 1410-8913 Aspire 1810T-35
GB-AC1450	TravelMate 8005LCib TravelMate 803LMib TravelMate 6003LCi TravelMate 663LCi TravelMate 8004LMib TravelMate 803LCib TravelMate 6002 TravelMate 661XVi TravelMate 802XCi Quanta Z500N Series TravelMate 661LMI TravelMate 8005 TravelMate 802LCiB Fe
GB-AC1700	Aspire 1700 series
GB-AC1800	Aspire 1800/1801/1802/1804
GB-AC1H	Aspire One series Acer Aspire One ZG5 (Linux) Acer Aspire One A110 Series Gateway LT 11.6" Series Gateway LT1000, Gateway LT1001, Gateway LT1001G, Gateway LT1001J, Gateway LT1004, Gateway LT1004U, Gateway LT1005, Gateway LT-1005C, Gateway LT1005U, Gateway
GB-AC1H	Aspire One series Acer Aspire One ZG5 (Linux) Acer Aspire One A110 Series Gateway LT 11.6" Series Gateway LT1000, Gateway LT1001, Gateway LT1001G, Gateway LT1001J, Gateway LT1004, Gateway LT1004U, Gateway LT1005, Gateway LT-1005C, Gateway LT1005U, Gateway

Battery

GB-AC2000	Aspire 2000 Series Aspire 2000LCi Aspire 2000LMi Aspire 2000WLCi Aspire 2000WLMi Aspire 2001 Aspire 2001LC Aspire 2001LCe Aspire 2001LCi Aspire 2001LMi Aspire 2001WLCi Aspire 2001WLMi Aspire 2002 Aspire 2002LCi Aspire 2002LMi Aspire 2002WLC
GB-AC210	TravelMate 210/210T/210TER/210TXF/211T/212T/212TE/212TVX/213T/213TX/213TXV/200/200DX/200T/201/201T/202/202T
GB-AC210	TravelMate 210/210T/210TER/210TXF/211T/212T/212TE/212TVX/213T/213TX/213TXV/200/200DX/200T/201/201T/202/202T
GB-AC2200	TravelMate 2200/2700/Aspire 1670
GB-AC2200H	TravelMate 2200/2700/Aspire 1670
GB-AC270	Aspire 1200/TravelMate 270/270X/272/272LC/272X / 272X/272Xi/273/273X/273X/275/275LC/A550 Acer Aspire : 1200 Series Acer TravelMate: 270, 270XV, 272LC, 272, 272X, 272XVi, 272XV, 273, 273X, 273XV, 275, 275LC, 530, 533Xci, 550, A550 Series Compal: Compal N-30
GB-AC280	TravelMate 220 Series TravelMate 222 Series TravelMate 222X TravelMate 223 Series TravelMate 223X TravelMate 223XC TravelMate 223XV TravelMate 225 Series TravelMate 225X TravelMate 225XC TravelMate 225XV TravelMate 225XV-Pro TravelMate 230 Ser

Battery

GB-AC290	Aspire 9010 Series Aspire 9100 Series Aspire 9100WLMi Aspire 9101WLMi Aspire 9102WLC Aspire 9102WLCi Aspire 9102WLMi Aspire 9103WLMi Aspire 9104LM Aspire 9104LMi Aspire 9104WLM Aspire 9104WLMi Aspire 9104WLMITV Aspire 9104WSMi Aspire 9105WLM
GB-AC300	TravelMate C300/C300Xci/C301/C301Xmi/C301XMib/C302/C302Xmi/C310
GB-AC3240	TravelMate 2420/3240/3280/3302/3304/5540/AS5560/AS5540/AS3640/AS3620 /AS3670
GB-AC3240H	TravelMate 2420/3240/3280/3302/3304/5540/AS5560/AS5540/AS3640/AS3620 /AS3670
GB-AC330	TravelMate 330/340/345/330T/332/332T/333/333T/340T/341/341T/342/342T/ 343/343T/345/345T/347/347T serie
GB-AC350	TravelMate/350/350te/351/352/352te/353/353te/353te/354/354te /354Te/5x 36x 360 361 361ei 364 364eci
GB-AC370	TravelMate 370/371/372/374/380/381/382/383/383TCi Series
GB-AC370H	TravelMate 370/371/372/374/380/381/382/383/383TCi Series
GB-AC3810	Aspire 3810 Timeline Series Aspire 3810T-6415 Aspire 3810T-8640 Aspire 3810TZ-4880 Aspire 4810 Timeline Series Aspire 4810-4439 Aspire 4810T-8480 Aspire 4810T-8702 Aspire 4810TZ-4011 Aspire 4810TZ-4696 Aspire 5810 Timeline Series Aspire 5810T-8929 Aspire
GB-AC3820	Acer TimelineX 3820T 4820TG 4820T 5820T series
GB-AC3935	Aspire 3935 series, Aspire 3935-6504, Aspire 3935-742G25Mn, Aspire 3935-744G25Mn, Aspire 3935-842G25Mn, Aspire 3935- 862G25Mn, Aspire 3935-864G32Mn, Aspire 3935-CF61, Aspire 3935- CF61F, Aspire 3935-MS2263

Battery

GB-AC4000	Extensa 3002WLM/Acer Aspire 1640Z series Acer Aspire 1410 Series Aspire 1411, Aspire 1411WLMi, Aspire 1412, Aspire 1412LC, Aspire 1412LCi, Aspire 1412LM, Aspire 1412LMi, Aspire 1412WLMi, Aspire 1413, Aspire 1413LC, Aspire 1413LM, Aspire 1413LMi, Aspire 1
GB-AC4006	Ferrari 4005WLMi Ferrari 4000 Series Ferrari 4001 Ferrari 4002 Ferrari 4002WLMi Ferrari 4003 Ferrari 4004 Ferrari 4005 Ferrari 4006 Ferrari 4006WLMi
GB-AC420	Acer TravelMate 420, 540 Acer Travelmate 430 Acer Travelmate 422 XC Acer Travelmate 426 LC Acer Travelmate 427 LC Acer Travelmate 430 Acer Aspire 2200 Arm, Chembook, Compal, HyperData APL10, APL11, BCQ12, CQ12, PL10, PL11 Compal CL11 Acer BATBCL
GB-AC4710	Aspire 4710G, Aspire 4310, Aspire 4520, Aspire 4920G, Aspire 4710Z, Aspire 4720, Aspire 4520G, Aspire 4720G, Aspire 4715, Aspire 4315
GB-AC4710H	Aspire 4710G, Aspire 4310, Aspire 4520, Aspire 4920G, Aspire 4710Z, Aspire 4720, Aspire 4520G, Aspire 4720G, Aspire 4715, Aspire 4315
GB-AC5100	Aspire 3100 Series Aspire 3103 Acer TravelMate 4200, TraveMate 4202 Aspire 3104WLMiB120 Aspire 3104WLMiB80 Aspire 3104WLMiB80F Aspire 3690 Series Aspire 3692WLCi Aspire 3693WLMi Aspire 5100 Series Aspire 5101 Aspire 5102 Aspire 5102AW
GB-AC520	TravelMate 529TXV TravelMate 521TXV TravelMate 525TE TravelMate 520 TravelMate 529ATXV HITACHI Flora 270GX NW1 PC-AB6000 TravelMate 527TXV TravelMate 524 TravelMate 530

Battery

GB-AC532	Acer Aspire one 532h all Series Acer aspire one 532h-2Db, Acer aspire one 532h-2Dr, Acer aspire one 532h-2Ds, Acer aspire one 532h-21s, Acer aspire one 532h-21b, Acer aspire one 532h-21r, Acer aspire one 532h-2223, Acer aspire one 532h-2227,
GB-AC5500	Acer Aspire 3050 Acer Aspire 3050WXM Acer Aspire 3053NWXCi Acer Aspire 3053NWXM Acer Aspire 3053WXCi Acer Aspire 3053WXM Acer Aspire 3054NWXCi Acer Aspire 3054NWXM Acer Aspire 3054WXCi Acer Aspire 3054WXM Acer Aspire 3600 Acer Aspire 3602NWXM Acer As
GB-AC5500H	Acer Aspire 3050 Acer Aspire 3050WXM Acer Aspire 3053NWXCi Acer Aspire 3053NWXM Acer Aspire 3053WXCi Acer Aspire 3053WXM Acer Aspire 3054NWXCi Acer Aspire 3054NWXM Acer Aspire 3054WXCi Acer Aspire 3054WXM Acer Aspire 3600 Acer Aspire 3602NWXM Acer As
GB-AC5920	Acer Aspire 5315 Series Aspire 5315, Aspire 5315-2001, Aspire 5315-2013, Aspire 5315-2077, Aspire 5315-2122, Aspire 5315-2142, Aspire 5315-2153, Aspire 5315- 2187, Aspire 5315-2191, Aspire 5315-2203, Aspire 5315-2270, Aspire 5315-2290, Aspire 5315-2326, As
GB-AC5920	Aspire 5310 Series, Aspire 5710 Series, Aspire 6920 Series, Aspire 7220 Series, Aspire 7720 Series, Aspire 8920 Series, Aspire 8930 Series
GB-AC610	Travelmate 610/611/612/613/614

Battery

GB-AC620	TravelMate 620Series TravelMate 623LC TravelMate 621 TravelMate 623LCI TravelMate 623 TravelMate 624 TravelMate 621LV TravelMate 621XV TravelMate 630Series TravelMate 621XC
GB-AC6410	Acer TravelMate 6410 Series TravelMate 6410 TravelMate 6413 TravelMate 6414 Acer TravelMate 6460 series TravelMate 6460 TravelMate 6463 TravelMate 6464 TravelMate 6465 Acer Extensa 5000 series Extensa 5210 Series, Extensa 5620G Series, Extensa 52
GB-AC6410	Acer TravelMate 6410 Series TravelMate 6410 TravelMate 6413 TravelMate 6414 Acer TravelMate 6460 series TravelMate 6460 TravelMate 6463 TravelMate 6464 TravelMate 6465 Acer Extensa 5000 series Extensa 5210 Series, Extensa 5620G Series, Extensa 52
GB-AC7000	Acer TravelMate 5100 Series, Acer TravelMate 5110 Series Acer Aspire 5600 Series Aspire 5600AWLMi, Aspire 5601AWLMi, Aspire 5602WLMi Acer Aspire 7000 Series Aspire 7003WSMi, Aspire 7004WSMi Acer Aspire 7100 Series Aspire 7103WSMi, Aspire 7104WSMi, Acer As
GB-AC751	Acer ASPIRE one pro 751 AO751 751H
GB-AC751	Acer Aspire one 751h, Acer Aspire one ZG8 751h a0751h
GB-AC751H	Acer Aspire one 751h, Acer Aspire one ZG8 751h a0751h
GB-AC751H	Acer Aspire one 751h, Acer Aspire one ZG8 751h a0751h

Battery

GB-AC8200	Acer Acer Ferrari 5000 Series Ferrari 5004WLMi, Ferrari 5005, Ferrari 5005WLHi, Ferrari 5005WLMi, Ferrari 5005WLMi-FR Acer TravelMate 8200 Series TravelMate 8202WLMi, TravelMate 8204WLM, TravelMate 8204WLMi, Tra
GB-AC8200	Acer Acer Ferrari 5000 Series Ferrari 5004WLMi, Ferrari 5005, Ferrari 5005WLHi, Ferrari 5005WLMi, Ferrari 5005WLMi-FR Acer TravelMate 8200 Series TravelMate 8202WLMi, TravelMate 8204WLM, TravelMate 8204WLMi, Tra
GB-ACDR35	Acer AcerNote 350 Series AcerNote 350, AcerNote 350C, AcerNote 350P, AcerNote 350PC, AcerNote 350PX AcerNote 352 Series AcerNote 355 Series AcerNote 356 Series AcerNote 358 Series AcerNote 358
GB-ACDR36	Acer Acer AcerNote A Series (Smart) AST AST Ascentia A Series Ascentia A, Ascentia A40, Ascentia A41, Ascentia A42, Ascentia A43, Ascentia A51, Ascentia A60, Ascentia A70, Ascentia A70 Plus, Ascentia AD40
GB-ACTM3000	A Ferrari 1000 SeriesFerrari 1000-5123Ferrari 1000-5612Ferrari 1000WTMiFerrari 1003Ferrari 1003WTMiFerrari 1004WTMiFerrari 1005Ferrari 1005WLMiFerrari 1005WTMiTravelMate 3000TravelMate 3010TravelMate 3030TravelMate 3040

Battery

GB-ACTM3000H Ferrari 1000 SeriesFerrari 1000-5123Ferrari 1000-5612Ferrari
1000WTMiFerrari 1003Ferrari 1003WTMiFerrari 1004WTMiFerrari
1005Ferrari 1005WLMiFerrari 1005WTMiTravelMate
3000TravelMate 3010TravelMate 3030TravelMate 3040

GB-ACTM3200 TravelMate C210 Series
TravelMate C200 Series
TravelMate C215Tmi
TravelMate C204Tmi
TravelMate C213Tmi
TravelMate C203ETCi
TM3200

GB-ACTM3200H TravelMate C210 Series
TravelMate C200 Series
TravelMate C215Tmi
TravelMate C204Tmi
TravelMate C213Tmi
TravelMate C203ETCi
TM3201

GB-AD6000 Advent
6000 7061M 7063M 7072 7078

Alphatop
G553 G556 G556e Green 553 Green 556 Green 556e

Excel
SlimNote G553 SlimNote G556

Gericom
Blockbuster Mobile G556 Overdose 1440e Overdose Radeon 9700,
IPC LifeStyle Centrino Expert G556

IPC Lifestyle Centr

Battery

GB-ADB55	Advent 7040 Averatec 5100 Series 5110 series 5110H, 5110HX, 5110P ELEMENTS MB05 F.I.C. MB05, MB05 Plus MB05C, MB05H MB05M, MB05P MB05T MB05W, MB05W Plus WB-B55 WB-B55-C HYUNDAI M-Life MB05 LIFETEC LT41100 MEDION FIM2010 MD41100 MD41164 ZITECH B55 MB05 WB-
GB-AP6138	Apple PowerBook G3 1998/G3 WallStreet
GB-AP7318	PowerBook G3 12.1" /G3 13.3" /G3 14.1" (1999 models) (2000 models)
GB-AP7621	Apple iBook Clamshell, Apple iBook M2453, Apple iBook 1999 model, Apple iBook 2000 model Apple iBook Blueberry Series, Apple iBook FireWire Series, Apple iBook Graphite Series , Apple iBook Indigo Series, Apple iBook Lime Green Series Apple iBook
GB-AP8244	Apple PowerBook G4 M8858LL/PowerBook G4 Titanium
GB-AP8416	iBook 14.1 LCD Series/14.1 LCD 16 VRAM/14.1 LCD 32 VRAM /iBook G3 14-inch Series
GB-AP8433	Apple iBook 12.1" Screen Dual USB/32 VRAM/Crystal White series/Dual USB 12 Inch/G3 12", Apple iBook G4 12 Inch/Late 2001 Model/M8861LLA/Opaque White 16 VRAM/Snow White series/White 12 Inch/White 12 Inch
GB-APA1039	PowerBook G4-17 inch Series

Battery

GB-APA1078	Apple PowerBook G4 15-inch Aluminum case This's not plastic case
GB-APA1078	Apple PowerBook G4 15-inch Aluminum series This's plastic case
GB-APA1079	Apple PowerBook G4 series 12.1 Inch TFT Wide Screen
GB-APA1175	APPLE 15"MacBook
GB-APA1185B	Apple Mac Book 13 inch
GB-APA1185B	Apple Mac Book 13 inch
GB-APA1185W	Apple Mac Book 13 inch
GB-APA1185W	Apple Mac Book 13 inch
GB-APA1189	APPLE 17"MacBook Pro
GB-APA1245	Apple 13 inch MacBook Air Series
GB-APA1280	13" New AUL Uni MacBook Series MacBook 13" A1278, MacBook 13" Aluminum Unibody Series(2008 Version), MacBook 13" MB466*/A, MacBook 13" MB466CH/A, MacBook 13" MB466J/A, MacBook 13" MB466LL/A, MacBook 13" MB466X/A, MacBook 13" MB467*/A, MacBook 13" MB467CH/
GB-APA1281	Apple 15-inch MacBook Pro Series MacBook Pro 15" A1286, MacBook Pro 15" Aluminum Unibody Series(2008 Version), MacBook Pro 15" MB470*/A, MacBook Pro 15" MB470CH/A, MacBook Pro 15" MB470J/A, MacBook Pro 15" MB470LL/A, MacBook Pro 15" MB470X/A, MacBook Pro 1
GB-APA1322	MacBook Pro 13" MB990LL/A MacBook Pro 13" MB991LL/A MacBook Pro A1322
GB-APA1331	APPLE MacBook 13" APPLE MacBook Unibody 13" APPLE MacBook Pro 15" APPLE MacBook Pro Unibody 15" APPLE MacBook Pro 17" APPLE MacBook Air APPLE MacBook Air MC234LL/A 13.3-Inch APPLE MacBook Air MC233LL/A 13.3-Inch APPLE MacBook Pro 13.3-Inch APP
GB-AS1005	AL31-1005 AL32-1005
GB-AS1005H	AL31-1005 AL32-1005
GB-AS101	Asus EEE PC S101 series
GB-AS101H	Asus EEE PC S101 series
GB-AS6	Asus S6 Series, S6F
GB-AS62	Asus S62, S96, Clevo M660, M661, M665, Compal GL30, GL31, EL80, EL81, HEL80, HEL81, HGL30, HGL31, Quanta SW1, TW3, TW5 series laptop notebook computers.
GB-AS6H	Asus S6 Series, S6F
GB-AS701	Asus Eee PC 701C Eeepc series
GB-AS701H	Asus Eee PC 701C Eeepc series
GB-AS701H	Asus Eee PC 701C Eeepc series
GB-AS701H	Asus Eee PC 701C Eeepc series
GB-AS701H	Asus Eee PC 701C Eeepc series
GB-AS901	Asus Eee 901Eee Pc 901 series

Battery

GB-AS901H	Asus Eee 901Eee Pc 901 series
GB-AS901H	Asus Eee 901Eee Pc 901 series
GB-AS901H	Asus Eee 901Eee Pc 901 series
GB-AS901H	Asus Eee 901Eee Pc 901 series
GB-ASA1	Asus A1 Series Asus A1000 Series Asus A1000B Series Asus A1000D Series Asus A1000F Series Asus A1200 Series, Asus A1200-C700 Series Asus A1300 Series, Asus A1300-P700 Series Asus A1B Series, Asus A1D Series, Asus A1F Series
GB-ASA2	A2, A2C, A2D, A2G, A2H, A2K, A2L, A2S, A2T, A2000, A2000C, A2000D, A2000G, A2000H, A2000K, A2000L, A2000S, A2000T, A2508H, A2514H, A2534H, Z80 Z8000 Z8000H
GB-ASA3	Asus: Asus A3500L, Asus A38N Asus A3 Series A3Ac, A3E, A3Fc, A3Fp, A3G, A3H, A3Hf, A3L, A3N, A3Vc, A3Vp Asus A3000 Series A3000, A3000E, A3000G, A3000L, A3000N Asus A6 Series A6E, A6F, A6G, A6J, A6Ja, A6Jc, A6Je, A6Jm, A6K, A6Km, A6Kt, A6L, A6M, A A4 Series A4000 Series A4000D Series A4000G Series A4000Ga Series A4000K Series A4000Ka Series A4000L Series A4000S Series A4D Series A4G Series A4Ga Series A4K Series A4Ka Series A4L Series A4S
GB-ASA4	
GB-ASA5	Asus A5

Battery

GB-ASA8	A8Jv A8Je A8He A8F A8 Series A8Js Z99Jn A8Jc Z99H F8Sv F8 Series A8Sr A8Jn A8Ja A8H A8E A8Sc Z99Sc A8Jr Z99Jc Z99Fm F8Sa A8Tm A8Le A8Jm A8J A8Fm A8Dc A8M Z99Jr A8Jp Z99J Z99 Series F8P
GB-ASA9T	A9T
GB-ASA9T	A9T
GB-ASF3	A9, A9C, A9R, A9Rp, A9Rt, A9T, A9W, F2 Series, F2F, F2Hf, F2J, F2Je, F3 Series, F3E, F3F, F3H, F3J, F3Ja, F3Jc, F3Jf, F3Jm, F3Jp, F3Jr, F3Jv, F3Ka, F3Ke, F3L, F3P, F3Q, F3Sa, F3Sc, F3Se, F3Sr, F3Sv, F3T, F3Tc, F3U, M51 Series, M51A, M51Kr, M51Se, M51Sn, M
GB-ASF3H	A9, A9C, A9R, A9Rp, A9Rt, A9T, A9W, F2 Series, F2F, F2Hf, F2J, F2Je, F3 Series, F3E, F3F, F3H, F3J, F3Ja, F3Jc, F3Jf, F3Jm, F3Jp, F3Jr, F3Jv, F3Ka, F3Ke, F3L, F3P, F3Q, F3Sa, F3Sc, F3Se, F3Sr, F3Sv, F3T, F3Tc, F3U, M51 Series, M51A, M51Kr, M51Se, M51Sn, M
GB-ASF5	Asus F5 Series Asus F5 Asus F5N Asus F5R
GB-ASF7	Asus F7000 L7 L7000 L7000B, L7000C, SFB-ASL7000L Asus L7200, Asus L7300, Asus L7400

Battery

GB-ASF9

Asus F9 Series

Asus F9

Asus F9DC

Asus F9E

Asus F9F

Asus F9J

Asus F9S

Asus Z53 Series

Asus Z53

Asus F6 Series

Asus F6

Asus F6E

Asus F6A

Asus F6K

Asus F6K54S-SL

Asus F6K233E-SL

GB-ASF9H

Asus F9 Series

Asus F9

Asus F9DC

Asus F9E

Asus F9F

Asus F9J

Asus F9S

Asus Z53 Series

Asus Z53

Asus F6 Series

Asus F6

Asus F6E

Asus F6A

Asus F6K

Asus F6K54S-SL

Asus F6K233E-SL

Battery

GB-ASK40	Asus K40 K40E Series Asus F82 F83S K40 K40E K6C11 Asus F52 SERIES Asus K50 SERIES Asus K51 SERIES Asus K60 SERIES Asus K61 SERIES Asus P50 SERIES Asus P81 SERIES Asus K70 SERIES Asus X65 X70 SERIES Asus X50 SERIES Asus X5D X5E X5C X5J X8B X8D SERIES Asus
GB-ASK52	Asus a52 series Battery Asus a52f Battery Asus a52j Battery Asus a52jb Battery Asus a52jk Battery Asus a52jr Battery Asus a52jr-x1 Battery Asus k42 series Battery Asus k42f Battery Asus k42f-a2b Battery Asus k42jb Battery Asus k42jk Battery Asus k42jr Bat
GB-ASL4	L4, L4E, L4H, L4L, L4R, L41, L42, L44, L45, L4000, L4000E, L4000H, L4000L, L4000R L4500, L4500R Series
GB-ASL5	L5000 Series Asus L5000C Series Asus L5G Series L5 Series L5000D Series L5000G Series L5500 Series L5800 Series L5900 Series L5C Series L5D Series
GB-ASL8	Asus L8 Series, Asus L8000 Series, Asus L8000B Series, Asus L8000C Series, Asus L8000Ce Series, Asus L8000F Series, Asus L8000K Series, Asus L8000L Series, Asus L84 Series, Asus L8400 Series, Asus L8400B Series, Asus L8400C Series, Asus L8400Ce
GB-ASM2	Asus L3 Series L3C, L3D, L3H, L3M, L3S, L3T Asus L3000 Series L3000, L3000C, L3000D, L3000S, L3100, L3400, L3400C, L3400S, L3420, L3500, L3500T, L3800, L3800C, L3800D, L3800S Asus M2000 Series M2000-A Series

Battery

GB-ASM3	M3, M3000, M3N, M3000N, M3Np, M3000Np
GB-ASM5	Asus M5 Series, Asus M5A Series, Asus M5N Series, Asus M500A Series, Asus M500N Series, Asus M5000 Series, Asus 5000A Series, Asus M5000N Series, Asus S5 Series, Asus S5A Series, Asus S6N Series,
GB-ASM50	Asus M50 M51 M50S M50Q M70 series
GB-ASM50	Asus M50 M51 M50S M50Q M70 series
GB-ASM5H	Asus M5 Series, Asus M5A Series, Asus M5N Series, Asus M500A Series, Asus M500N Series, Asus M5000 Series, Asus 5000A Series, Asus M5000N Series, Asus S5 Series, Asus S5A Series, Asus S6N Series,
GB-ASM6	Asus M6 Series, Asus M6N Series, Asus M67 Series, Asus M67N Series, Asus M68 Series, Asus M68N Series, Asus M6000 Series, Asus M6000N Series Asus M6700 Series, Asus M6700N Series Asus M6800 Series, Asus M6800N Series
GB-ASM7	M7, M7V, Z70V, Z7000V, Z7100V, Z71V ISSAM SmartBook i5500S, i5500V
GB-ASM9	Asus Asus M9 Series M9A, M9F, M9J, M9VCompaq Compaq Presario B2800 Series Presario B2801TX, Presario B2802TX, Presario B2803TX, Presario B2804TX, Presario B2805TX, Presario B2806TX, Presario B2807TX, Presario B28

Battery

GB-ASM9H	Asus Asus M9 Series M9A, M9F, M9J, M9V Compaq Compaq Presario B2800 Series Presario B2801TX, Presario B2802TX, Presario B2803TX, Presario B2804TX, Presario B2805TX, Presario B2806TX, Presario B2807TX, Presario B28
GB-ASN50	Asus N50 N50VN N50VC Series
GB-ASP21	Eee PC 1002HA, Eee PC S101H, S101H-BLK042X, S101H-BRN043X, S101H-CHP035X, S101H-PIK025X
GB-ASR1	Asus R1 Series Tablet PC R1E R1F
GB-ASR2	Asus C22-R2
GB-ASR2	Asus C22-R2
GB-ASU1	Asus Asus U1 Series U1F, U1E Asus U3 Series U3S, U3Sg
GB-ASU1H	Asus Asus U1 Series U1F, U1E Asus U3 Series U3S, U4Sg
GB-ASU5	Asus Asus U5 Series U5A, U5F
GB-ASU5H	Asus Asus U5 Series U5A, U5F
GB-ASU6	Asus Asus U6S, Asus U6Sg, Asus U6V, Asus U6Vc, Asus U6E, Asus U6Ep Asus N20 Series N20A

Battery

GB-ASU6H	<p>Asus Asus U6S, Asus U6Sg, Asus U6V, Asus U6Vc, Asus U6E, Asus U6Ep</p> <p>Asus N20 Series N20A</p>
GB-ASU80	<p>Asus U Series Laptops U30, U50, U80. Asus U80 U80V U80A</p>
GB-ASUL30	<p>Asus UL30 series Asus UL30A, UL30A-A1, UL30A-A2, UL30A-A3B, UL30A-X1, UL30A-X2, UL30A-X3, UL30A-X4, UL30A-X5, UL30A-QX130X, UL30A-QX131X</p> <p>Asus UL50 series Asus UL50AG-A2, UL50Ag-A3B, UL50Vg, UL50Vg-A2, UL50VS-A1B, UL50Vt, UL50Vt-A1, UL50Vt-X1, UL50Vt-</p>
GB-ASV1	<p>V1J V1Jp V1S V1 Series VX2-Lamborghini VX2S-Lamborghini</p>
GB-ASW1	<p>W1000Ga W1000N W1000 W1N W1G W1000V W1000Gc W1V W1Gc W1 W1000Na W1000G W1Na W1Ga</p>
GB-ASV2	<p>Asus V2</p>
GB-ASW2	<p>Asus W2J W2Jb W2Jc W2P W2Pb W2Pc W2V W2Vc</p>
GB-ASW3	<p>W3, W3A, W3N, W3V W3000, W3000A, W3000V SERIES</p>
GB-ASW3H	<p>W3, W3A, W3N, W3V W3000, W3000A, W3000V SERIES</p>
GB-ASV6	<p>V6, V6V, V6000, V6000V VX1, VX1-Lamborghini series,</p>
GB-ASW90	<p>Asus W90 Asus W90V Asus W90VN Asus W90VP Asus W90vp-a1 Asus W90vp-a2 Asus W90vp-x1 Asus W90vp-x2</p>

Battery

GB-ASX51	Asus X51H X51L X51R X51RL
GB-ASX71	Asus M70V Series
	Asus X71 Series
	Asus G71 Series
	Asus X72 Series
	Asus N70SV Series
GB-ASZ37	Asus Z37 Z37K Z37E Z37S series
GB-ASZ37H	Asus Z37 Z37K Z37E Z37S series
GB-AV2150	Advent 7066M
	Averatec AV2155EH1
	Averatec AV2150EH1 AV2150EH1R
	Averatec AV2150EH1
	Averatec 2155 2155-EH1
	Averatec 2155
	Averatec 2150 2150-EH1
	Averatec 2150
	Averatec 2100 2100-EH1
	Averatec 2100
	LITTLEBIT Pearl X32
	MEDION SIM2000 (XG-650)
	MEDION
GB-AV3000	Averatec 3000 Series, Averatec 3000H, Averatec 3000HD
	Averatec 3050HS, Averatec 3050HW, Averatec 3050P
	Averatec 3120 Series, Averatec 3150 Series, Averatec 3200 Series
	Averatec 3360EG, Averatec 3360EH, Averatec AV3220H1-01
	Averatec AV3225HS-20, Averatec A
GB-AVT14	Haier A32-T14 T68
GB-AVT66	HAIER T66 TS44A
	Founder S650 S650A S650N
GB-BQ5000	BENQ
	BenQ JoyBook 5000 Series,
	BenQ JoyBook 5100 Series,
	BenQ JoyBook 5200 Series,
	BenQ JoyBook S5000 Series,
	BenQ JoyBook S5100 Series
GB-BQ6000	BENQ
	BenQ JoyBook 6000 Series,
	BenQ JoyBook 6000E Series,
	BenQ JoyBook 6000N Series,
	BenQ JoyBook DH6000 Series
GB-BQ7000	BENQ
	BenQ JoyBook 7000 Series,
	BenQ JoyBook 7000N Series,
	BenQ JoyBook S72 Series

Battery

GB-BQS53	BENQ BenQ JoyBook S53 Series, BenQ JoyBook S53E Series, BenQ JoyBook S53W Series
GB-BQU101	BenQ Joybook Lite U101 Series
GB-BQU101H	BenQ Joybook Lite U101 Series
GB-BQU101H	BenQ Joybook Lite U101 Series
GB-CD470	Clevo D470 D410E D400H Portanote D400H Portanote D470 Portanote D410E Portanote D400E Desknote D470 Desknote D410E Desknote D400E QXS-BAT-ION HYPERDATA D470W 4700 IPC Mnote 410S MEDION D400S PRISMA Prismabook D400S D410S D410 D400E Desk Clevo D22ES 2200 2700T D27ES M270S M22BAT-8 2700C 2800 2200C D220S D270S M220S 2700 2200T 2800T Gericom T1130 OVERDOES T OVERDOES OVERDOES S OVERDOES III OVERDOES S2 OVERDOES S3
GB-CL2700	

Battery

GB-CL700T	Clevo PortaNote Promedion D700T D750W series
GB-CLM120	Clevo MobiNote M120 MobiNote M120C MobiNote M120W MobiNote M121 MobiNote M121C MobiNote M121W series
GB-CLM300	Clevo M300N, M310N, M350B, M360C, M350C, M361C Series, M362C, M375C, M375E, M375EW, M37EW, M385C Series
GB-CLM400	Clevo MobiNote M400A M400G M450C
GB-CLM540	MobiNote M54G, MobiNote M54V, MobiNote M55G, MobiNote M55V MobiNote M540G, MobiNote M540V, MobiNote M541G, MobiNote M541V MobiNote M545G, MobiNote M545V, MobiNote M550G, MobiNote M550V, MobiNote M551G, MobiNote M551V, MobiNote M555G, MobiNote M555V Series
GB-D100N	Inspiron 2600, 2650 Series, Smart PC 100N, WinBook N4
GB-D1210	Dell XPS M1210 NF343 CG036 451-10357 312-0435 HF674 451-10371 451-10356 CG039 451-10370 312-0436
GB-D1210H	Dell XPS M1210 NF343 CG036 451-10357 312-0435 HF674 451-10371 451-10356 CG039 451-10370 312-0437
GB-D1220	Dell Vostro 1220 Series
GB-D1300	Inspiron 1300 Series
GB-D1300	Inspiron B/ B120/B130/1300 Series
GB-D1300H	Inspiron B/ B120/B130/1300 Series
GB-D1310	Dell Vostro 1310 / 1510 /2510 SERIES

Battery

GB-D1310	Dell Vostro 1310 / 1510 /2510 SERIES
GB-D1310H	Dell Vostro 1310 / 1510 /2510 SERIES
GB-D1320	Dell Inspiron 1320 /Dell Inspiron 1320n
GB-D1330	XPS M1330 Series
GB-D1330H	XPS M1330 Series
GB-D1340	Studio XPS 13, Studio XPS 1340
GB-D1340H	Studio XPS 13, Studio XPS 1340
GB-D1370	Dell Inspiron 13z 1370 Sereis
GB-D1370H	Dell Inspiron 13z 1370 Sereis
GB-D1420	Inspiron 1420, 1400
GB-D1420H	Inspiron 1420, 1401
GB-D1435	Studio 1435, Studio 1436
GB-D1440	Dell Inspiron 1440 /1750
GB-D1440	Dell Inspiron 1440 /1750
GB-D1440H	Dell Inspiron 1440
GB-D1470	Dell Inspiron 14z Sereis Dell Inspiron 1470 Sereis Dell Inspiron 15z Sereis Dell Inspiron 1570 Sereis
GB-D1470H	Dell Inspiron 14z Sereis Dell Inspiron 1470 Sereis Dell Inspiron 15z Sereis Dell Inspiron 1570 Sereis
GB-D1520	Vostro 1700 Inspiron 1720 Vostro 1500 Inspiron 1521 Inspiron 1721 Inspiron 1520
GB-D1520H	Vostro 1700 Inspiron 1720 Vostro 1500 Inspiron 1521 Inspiron 1721 Inspiron 1520
GB-D1525	Inspiron 1525 /1526/1545, Inspiron 1526
GB-D1525H	Inspiron 1525 /1526/1545, Inspiron 1526
GB-D1530	XPS M1530
GB-D1530H	XPS M1530
GB-D1535	DELL Studio 1535 / 1536 SERIES
GB-D1535	DELL Studio 1535 / 1536 SERIES
GB-D1535H	DELL Studio 1535 / 1536 SERIES
GB-D1640	DELL Studio XPS 16, DELL Studio XPS 1640, DELL Studio XPS M1640 Series
GB-D1640H	DELL Studio XPS 16, DELL Studio XPS 1640, DELL Studio XPS M1640 Series

Battery

GB-D1720	Dell Vostro 1710, Vostro 1720 (US, CA, UK, DE, FR, JP, AU)
GB-D1720H	Dell Vostro 1710, Vostro 1720 (US, CA, UK, DE, FR, JP, AU)
GB-D1735	DELL Studio 1735 1736 SERIES
GB-D1735H	DELL Studio 1735 1737 SERIES
GB-D1745	Dell Studio 17 1745 1747 1749 Series
GB-D1745H	Dell Studio 17 1745 1747 1749 Series
GB-D2010	XPS M2010 Series
GB-D2010H	XPS M2010 Series
GB-D2100	Dell Latitude 2100
GB-D2200	Inspiron 1000/1200/2200/NEC E6000/E2000
GB-D3000	DELL Inspiron 3000 Inspiron 3000 M233ST Inspiron 3000 M266XT Inspiron 3200
	HP Omnibook 2100 Series OmniBook 2100, OmniBook 2103, OmniBook 2104, OmniBook 2105, OmniBook 2106, OmniBook 2120, OmniBook 2121, OmniBo
GB-D3500	Inspiron3500/3500 D233XT/3500 D266GT/3500 D300GT
GB-D400	Latitude D400 Series
GB-D410	Latitude D410/D410 53WH Series
GB-D410H	Latitude D410/D410 53WH Series
GB-D420	Latitude D420 /D430
GB-D420H	Latitude D420 /D430
GB-D500	Dell Inspiron 520 Series
GB-D5000	DELL DELL Inspiron 5000 Series Inspiron 5000, Inspiron 5000E
	WinBook COMPUTER WinBook Z Series WinBook Z1 Series
GB-D500H	DELL Dell Inspiron 500m Series, Dell Inspiron 510m Series, Dell Inspiron 600m Series, Dell Latitude D500 Series, Dell Latitude D505 Series, Dell Latitude D510 Series, Dell Latitude D520 Series, Dell Latitude D600 Series,

Battery

GB-D5100	Dell Inspiron 1100 Series Inspiron 1150
	Dell Inspiron 5100 Series Inspiron 5150, Inspiron 5160
GB-D5100H	Dell Latitude 100L Dell Inspiron 1100 Series Inspiron 1150
	Dell Inspiron 5100 Series Inspiron 5150, Inspiron 5160
	Dell Latitude 100L
GB-D6000	Inspiron 6000/9200/9300/9400/M170/M1710/E1505/E1705
GB-D6000H	Inspiron 6000/9200/9300/9400/M170/M1710/E1505/E1705
GB-D620	Latitude D620
GB-D620	Latitude D620
GB-D620H	Latitude D620
GB-D620H	Latitude D620
GB-D630M	Dell Inspiron Series, Inspiron 630m, Inspiron 640m, Inspiron E1405
GB-D630MH	Dell Inspiron Series, Inspiron 630m, Inspiron 640m, Inspiron E1405
GB-D6400	Dell Inspiron 6400 Dell Inspiron 1501 Dell Inspiron E1505 Dell Vostro 1000
GB-D6400H	Dell Inspiron 6400 Dell Inspiron 1501 Dell Inspiron E1505 Dell Vostro 1000

Battery

GB-D7000	DELL Inspiron 7000 Series Inspiron 7000, Inspiron 7000 D300LT, Inspiron 7000 D266GT Inspiron 7500 Series Inspiron 7500 COMPAL Compal TS30I HP Omnibook 7100 Omnibook 7150 PIONES PIONES TS30I QUANTEX
GB-D700M	Inspiron 700m/710m Series Dell 312-0305 Dell 312-0306 Dell 40006540 Dell 40007022 Dell BTP-82M Dell BTP-83M Dell C5498 Dell C6017 Dell C6269 Dell C7786 Dell D5561 Dell D7310 Dell F5136 Dell F5188 Dell G5345 Dell M6407 Dell MY982 Dell PC-AB7100 Dell P
GB-D700MH	Inspiron 700m/710m Series Dell 312-0305 Dell 312-0306 Dell 40006540 Dell 40007022 Dell BTP-82M Dell BTP-83M Dell C5498 Dell C6017 Dell C6269 Dell C7786 Dell D5561 Dell D7310 Dell F5136 Dell F5188 Dell G5345 Dell M6407 Dell MY982 Dell PC-AB7100 Dell P
GB-D800	Inspiron 8500 Series Inspiron 8600 Series Latitude D800 Series Precision M60 Mobile Workstation
GB-D800H	Inspiron 8500 Series Inspiron 8600 Series Latitude D800 Series Precision M60 Mobile Workstation
GB-D810	Latitude D810/M70
GB-D810H	Latitude D810/M70
GB-D820	DELL Dell Latitude D531, Dell Latitude D820, Dell Precision M65
GB-D820H	DELL Dell Latitude D531, Dell Latitude D820, Dell Precision M65

Battery

GB-D860	Dell Vostro A840 Dell Vostro PP37L Dell Vostro A860 Dell Vostro PP38L
GB-D910	DELL Mini 9 DELL Inspiron 910 DELL PP39S
GB-D9100	Inspiron 9100
GB-D9100H	Inspiron 9100
GB-D910H	DELL Mini 9 DELL Inspiron 910 DELL PP39S
GB-DC400	Latitude C400 series
GB-DC800	DELL Dell Precision Workstation M50 Dell Latitude C Series Dell Latitude C, Dell Latitude CP, Dell Latitude CPXH 500GT Dell Latitude C500, Dell Latitude C510, Dell Latitude C540, Dell Latitude C600, Dell Latitude C
GB-DCS	Latitude CS/CSX Series
GB-DCS	Latitude CS/CSX Series
GB-DE4200	DELL Latitude E4200
GB-DE4200H	DELL Latitude E4200
GB-DE5400	DELL LATITUDE 5400 5500 series
GB-DE5400H	DELL LATITUDE 5400 5500 series
GB-DE6500	Dell Latitude E6500 E6400 Dell Precision M2400 M4300 M4400 M6400
GB-DE6500H	Dell Latitude E6500 E6400 Dell Precision M2400 M4300 M4400 M6400
GB-DLS	Inspiron2000/2100/2800/Latitude L400 /LS/ LS 400 /LST C400ST Gateway Solo 3300 / 3350 / 3350CS
GB-DM1010	Mini 10 10v 1010 1011 Series Inspiron 11z 1110 Series
GB-DM1010H	Mini 10 10v 1010 1011 Series Inspiron 11z 1110 Series
GB-DM12	Dell Inspiron mini 12 series
GB-DM12H	Dell Inspiron mini 12 series
GB-DM12H	Dell Inspiron mini 12 series
GB-DM1730	Dell XPS M1730
GB-DV1200	DELL Vostro 1200 Series
GB-DV1200H	DELL Vostro 1200 Series

Battery

GB-DX1	Latitude X1
GB-DX1H	Latitude X1
GB-DX200	Latitude X200 Series
GB-DX200H	Latitude X200 Series
GB-DX300	Inspiron 300M/Latitude X300 Series
GB-DX300H	Inspiron 300M/Latitude X300 Series
GB-DXT	DELL XT Tablet PC
GB-DXTH	DELL XT Tablet PC
GB-U2	Digital Hi Note Ultra II
GB-VP700	DIGITAL HINOTE VP700 battery DIGITAL HINOTE VP715 battery DIGITAL HINOTE VP725 battery DIGITAL HINOTE VP735 battery DIGITAL HINOTE VP745 battery DIGITAL HINOTE VP763 battery DIGITAL HINOTE VP765 battery
GB-EM5000	Medion Emachine M5310 40004163, AQBT01, AQBT02, B-5804-32096-1801, NBACEM2747BT, W720-44LA, W720-44LB, W72044LA, W72044LB Advent 40004163 A0510 AQBT01 AQBT02 B-5804-32096-1801 EM-M5000 NBACEM2747BT W720 44LA W720 44LB W72044LA W720-44LA W72044LB W720
GB-F1520	Fujitsu-Siemens Amilo Si1520 , Si 1520 Fujitsu-Siemens Amilo Pro V3205 Fujitsu-Siemens Amilo Pro 564E1GB
GB-F3650	Fujitsu-Siemens Amilo Sa 3650
GB-F6800	Fujitsu Amilo EL6800, EL6810 Series Uniwill N243, N243SA, N243S, N243S1, N243S2, N243S9, N243SB, N244 Series ARM N243 N244 series Gericom N243 N244 series HYPERDATA N243 N244 series SCEPTRE N243

Battery

GB-F6800	Fujitsu Amilo EL6800, EL6810 Series Uniwill N243, N243SA, N243S, N243S1, N243S2, N243S9, N243SB, N244 Series ARM N243 N244 series Gericom N243 N244 series HYPERDATA N243 N244 series SCEPTRE N243
GB-FA1650	Fujitsu-Siemens Amilo A1650, A1650G Series Fujitsu-Siemens Amilo Pro V2040, V2045, V2060, V2065, V2085 series
GB-FA1655	Amilo 1655G Fujitsu-Siemens Amilo A-1655 A-1655G A1655G CEX KR2WFSS6
GB-FBP102	FUJITSU: Fujitsu FMV-BIBLO LOOX Series FMV-BIBLO LOOX P70R, FMV-BIBLO LOOX P70S Fujitsu FMV-LIFEBOOK Series FMV-LIFEBOOK P8210, FMV-LIFEBOOK P8240 Fujitsu LifeBook P Series LifeBook P1510, LifeBook P1510D, LifeBook P1610, LifeBook P1630
GB-FBP102H	FUJITSU: Fujitsu FMV-BIBLO LOOX Series FMV-BIBLO LOOX P70R, FMV-BIBLO LOOX P70S Fujitsu FMV-LIFEBOOK Series FMV-LIFEBOOK P8210, FMV-LIFEBOOK P8240 Fujitsu LifeBook P Series LifeBook P1510, LifeBook P1510D, LifeBook P1610, LifeBook P1630
GB-FBP104	LifeBook N6110 LifeBook N6410 LifeBook N6420
GB-FBP112	FMV-LifeBook B8200 LifeBook B6000D LifeBook B6110 LifeBook B6110 LifeBook B6110D

Battery

GB-FBP112H	FMV-LifeBook B8200 LifeBook B6000D LifeBook B6110 LifeBook B6110 LifeBook B6110D
GB-FBP115	LifeBook C1320, LifeBook C1321, LifeBook C1320D, LifeBook C1321D
GB-FBP116	LifeBook C1321, LifeBook C1320, LifeBook C1320D
GB-FBP118	FMV-BIBLO MG FMV-BIBLO MG50G FMV-BIBLO MG50H FMV-BIBLO MG50J FMV-BIBLO MG50K FMV-BIBLO MG50K/T FMV-BIBLO MG50KN FMV-BIBLO MG50L FMV-BIBLO MG50L/T FMV-BIBLO MG50LN FMV-BIBLO MG70G FMV-BIBLO MG70G/ST FMV-BIBLO MG75G Fujitsu LifeBook S
GB-FBP120	LifeBook N-3400, Fujitsu LifeBook N-3410, Fujitsu LifeBook N-3430, Fujitsu LifeBook N3400, FujitsuLifeBook N3410, Fujitsu LifeBook N3430
GB-FBP120H	LifeBook N-3400, Fujitsu LifeBook N-3410, Fujitsu LifeBook N-3430, Fujitsu LifeBook N3400, FujitsuLifeBook N3410, Fujitsu LifeBook N3430
GB-FBP130	Fujitsu FMV-BIBLO LOOX T50 Series FMV-BIBLO LOOX T50M, FMV-BIBLO LOOX T50R, FMV-BIBLO LOOX T50RN, FMV-BIBLO LOOX T50S, FMV-BIBLO LOOX T50SN Fujitsu FMV-BIBLO LOOX T70 Series FMV-BIBLO LOOX T70M, FMV-BIBLO LOOX T70MN, FMV-BIBLO LOOX T70M/T, FMV-BIBLO LOO
GB-FBP130H	Fujitsu FMV-BIBLO LOOX T50 Series FMV-BIBLO LOOX T50M, FMV-BIBLO LOOX T50R, FMV-BIBLO LOOX T50RN, FMV-BIBLO LOOX T50S, FMV-BIBLO LOOX T50SN Fujitsu FMV-BIBLO LOOX T70 Series FMV-BIBLO LOOX T70M, FMV-BIBLO LOOX T70MN, FMV-BIBLO LOOX T70M/T, FMV-BIBLO LOO
GB-FBP142	• FUJITSULifeBook C6611FMV-BIBLO NE8/1000HFMV-BIBLO NB50HFMV-7180NU4/BXLifeBook C2111FMV-BIBLO NE8/900WFMV- BIBLO NB55E/TFMV-BIBLO NB10ARLifeBook C2010FMV-BIBLO NE9/1130MFMV-BIBLO NB55HFMV-BIBLO NB14AFMV-BIBLO RS18D/STFMV-BIBLO NB7/80CFMV-BIBLO NB15BFMV-BI
GB-FBP144	FUJITSU LifeBook E8110 LifeBook E8210 FUJITSU-SIEMENS LifeBook E8110 LifeBook E8210

Battery

GB-FBP145	FUJITSU: Fujitsu FMV-S8220, Fujitsu FMV-S8225, Fujitsu FMV-S8250 Fujitsu FMV-BIBLO Series FMV-BIBLO MG50S, FMV-BIBLO MG50SN, FMV-BIBLO MG50U, FMV-BIBLO MG50U/V, FMV-BIBLO MG50W, FMV-BIBLO MG55S, FMV-BIBLO MG55SN, FMV-BIBLO MG55U, FMV-BIBLO MG57SN,
GB-FBP147	Q2010FMV-BIBLO LOOX Q70TNFMV-Q8240FMV-Q8230FMV-Q8220• FUJITSU-SIEMENSLifeBook Q2010
GB-FBP149	LifeBook Q2010FMV-BIBLO LOOX Q70TNFMV-Q8240FMV- Q8230FMV-Q8220• FUJITSU-SIEMENSLifeBook Q2010
GB-FBP151	FUJITSU LifeBook C1410
GB-FBP152	FMV-LifeBook B8220 FMV-LIFEBOOK B8250 FMV-LIFEBOOK TC8230 LifeBook B6210 LifeBook B6220
GB-FBP155	LifeBook T4210 LifeBook T4215 LifeBook T4220 Tablet PC
GB-FBP160	Lifebook A3110 LifeBook A3120 Lifebook A3130 Lifebook A6010 LifeBook A6020 LifeBook A6025 LifeBook A6030 LifeBook A6110
GB-FBP160H	Lifebook A3110 LifeBook A3120 Lifebook A3130 Lifebook A6010 LifeBook A6020 LifeBook A6025 LifeBook A6030 LifeBook A6110
GB-FBP171	LifeBook P7230
GB-FBP176	FUJITSU: Fujitsu LifeBook E8410, Fujitsu LifeBook N7010
GB-FBP177	FUJITSU: Fujitsu LifeBook S6410, Fujitsu LifeBook S6421, Fujitsu LifeBook S6510, Fujitsu LifeBook S7210, Fujitsu LifeBook S7211
GB-FBP182	FUJITSU: Fujitsu FMV Series FMV-BIBLO LOOX U50WN, FMV-BIBLO LOOX U50X/V, FMV-BIBLO LOOX U50XN, FMV-U8240, FMV-U8250 Fujitsu LifeBook Series LifeBook U1010, LifeBook U810

Battery

GB-FBP182H	FUJITSU: Fujitsu FMV Series FMV-BIBLO LOOX U50WN, FMV-BIBLO LOOX U50X/V, FMV-BIBLO LOOX U50XN, FMV-U8240, FMV-U8250 Fujitsu LifeBook Series LifeBook U1010, LifeBook U810
GB-FBP186	FUJITSU: Fujitsu FMV-BIBLO LOOX T50U, Fujitsu FMV-BIBLO LOOX T50U/V, Fujitsu FMV-BIBLO LOOX T70U, Fujitsu LifeBook T2010 Tablet PC
GB-FBP192	FUJITSU: Fujitsu FMV-A6250, Fujitsu FMV-A8250, Fujitsu LifeBook A1110, Fujitsu Lifebook V1010, Fujitsu LifeBook V1020
GB-FBP194	FUJITSU: Fujitsu LifeBook P8010, Fujitsu LifeBook P8020
GB-FBP198	LifeBook A6210
GB-FBP201	LifeBook U2010, U820
GB-FBP207	Stylistic ST6012
GB-FBP207H	Stylistic ST6012
GB-FBP216	FMV-BIBLO LOOX M/D10, FMV-BIBLO LOOX M/D15, LifeBook M2010
GB-FBP216H	FMV-BIBLO LOOX M/D10, FMV-BIBLO LOOX M/D15, LifeBook M2010
GB-FBP36	FMV-680MC4FMV-660MC9/WFMV-650MC8/WLifeBook B2620LifeBook B2566LifeBook B2545LifeBook B2175AFMV- 670MC3FMV-650MC8/W2LifeBook B2610LifeBook B2562LifeBook B2542LifeBook B2175FMV-665MC2FMV-650MC8/W1LifeBook B2630LifeBook B2569LifeBook B2547LifeBook B2175B

Battery

GB-FBP50	FUJITSU Fujitsu Lifebook P1100 Series Fujitsu Lifebook P1110, Fujitsu Lifebook P1120 Fujitsu Lifebook P2000 Series Fujitsu Lifebook P2040, Fujitsu Lifebook P2046, Fujitsu Lifebook P2110, Fujitsu
GB-FBP50H	FUJITSU Fujitsu Lifebook P1100 Series Fujitsu Lifebook P1110, Fujitsu Lifebook P1120 Fujitsu Lifebook P2000 Series Fujitsu Lifebook P2040, Fujitsu Lifebook P2046, Fujitsu Lifebook P2110, Fujitsu
GB-FBP59	FUJITSU LifeBook E2010 Series LifeBook E4010 Series LifeBook E4010D Series LifeBook E7010 Series LifeBook E7110 Series FMV Series FMV-7180MR3 FMV-7160MR2 FMV BIBLO Series FMV BIBLO MR16B FMV BIBLO MR16AH FMV BIBLO MG75E
GB-FBP63	Stylistic ST4000 Series Stylistic ST4000P Stylistic ST4110 Stylistic ST4110P Stylistic ST4121P Stylistic ST4120 Stylistic ST4120P Stylistic ST4121 Stylistic ST5000 Series Stylistic ST5000/D Stylistic ST5010 Stylistic ST5010D Stylistic ST5011 Stylistic
GB-FBP63H	Stylistic ST4000 Series Stylistic ST4000P Stylistic ST4110 Stylistic ST4110P Stylistic ST4121P Stylistic ST4120 Stylistic ST4120P Stylistic ST4121 Stylistic ST5000 Series Stylistic ST5000/D Stylistic ST5010 Stylistic ST5010D Stylistic ST5011 Stylistic
GB-FBP64	Lifebook S2000/S2020/S6120/S6120D/S2010/S2010/S6110/S6110/S6130/S6130
GB-FBP65	LIFEBOOK C2210/C2220/C2230/C2240 SERIES
GB-FBP68	FMV-BIBLO LOOX T50E, FMV-BIBLO LOOX T50E/W, FMV-BIBLO LOOX T50G/W, FMV-BIBLO LOOX T55G, FMV-BIBLO LOOX T60D, FMV- BIBLO LOOX T60D/W, FMV-BIBLO LOOX T70E, FMV-BIBLO LOOX T70G, FMV-BIBLO LOOX T90D, FMV-LIFEBOOK 7090MT4, Lifebook B3000D, LIFEBOOK B3010D, LIFE

Battery

GB-FBP80	FUJITSU Fujitsu Lifebook S6000 Series, Fujitsu Lifebook S6200 Series, Fujitsu Lifebook S6210 Series, Fujitsu Lifebook S6220 Series, Fujitsu Lifebook S6230 Series, Fujitsu Lifebook S6231 Series
GB-FBP82	Lifebook S7000S7000/DS7010S7010DS7020 S7020DFMV-Lifebook S8000/S8205/S8305 Series
GB-FBP83	FMV-BIBLO NB50J, FMV-BIBLO NB50K, FMV-BIBLO NB50KP, FMV- BIBLO NB55J, FMV-BIBLO NB55J/T, FMV-BIBLO NB55K, FMV-BIBLO NB55K/T, FMV-BIBLO NB55L/T, FMV-BIBLO NB70G, FMV-BIBLO NB70H/T, FMV-BIBLO NB75G, FMV-BIBLO NB75G/T, FMV-BIBLO NB75H, FMV-BIBLO NB75H/T, FMV-
GB-FBP83	FMV-BIBLO NB50J, FMV-BIBLO NB50K, FMV-BIBLO NB50KP, FMV- BIBLO NB55J, FMV-BIBLO NB55J/T, FMV-BIBLO NB55K, FMV-BIBLO NB55K/T, FMV-BIBLO NB55L/T, FMV-BIBLO NB70G, FMV-BIBLO NB70H/T, FMV-BIBLO NB75G, FMV-BIBLO NB75G/T, FMV-BIBLO NB75H, FMV-BIBLO NB75H/T, FMV-
GB-FBP86	Fujitsu FMV-BIBLO LOOX T50 Series FMV-BIBLO LOOX T50H, FMV-BIBLO LOOX T50J, FMV-BIBLO LOOX T50K
	Fujitsu FMV-BIBLO LOOX T70 Series FMV-BIBLO LOOX T70H, FMV-BIBLO LOOX T70J, FMV-BIBLO LOOX T70K, FMV-BIBLO LOOX T70K
GB-FBP91	Lifebook C Series Lifebook C1211 Lifebook C1211D Lifebook C1212 Lifebook C1212D Lifebook E Series Lifebook E8010 Lifebook E8010D Lifebook E8020 Lifebook E8020D
GB-FBP91	Lifebook C Series Lifebook C1211 Lifebook C1211D Lifebook C1212 Lifebook C1212D Lifebook E Series Lifebook E8010 Lifebook E8010D Lifebook E8020 Lifebook E8020D
GB-FBP92	LifeBook N6000 LifeBook N6010 LifeBook N6010 LifeBook N6200 LifeBook N6200 LifeBook N6210 LifeBook N6220

Battery

GB-FBP92H	LifeBook N6000 LifeBook N6010 LifeBook N6010 LifeBook N6200 LifeBook N6200 LifeBook N6210 LifeBook N6220
GB-FBP94	FUJITSU : LifeBook N3500 LifeBook N3510 Series Lifebook N3511 LifeBook N3520 LifeBook N3530
GB-FBP94H	FUJITSU : LifeBook N3500 LifeBook N3510 Series Lifebook N3511 LifeBook N3520 LifeBook N3530
GB-FBP95	F/T4010 FMV-BIBLO MG12B FMV-BIBLO MG12B/M FMV-BIBLO MG12C FMV-BIBLO MG12C/M FMV-BIBLO MG12D FMV-BIBLO MG13D FMV-BIBLO MG17D/A FMV-BIBLO MG50E FMV-BIBLO MG50M FMV-BIBLO MG50M/T FMV-BIBLO MG50R/T FMV-BIBLO MG55E FMV-BIBLO MG55R FMV-B
GB-FD9500	Fujitsu Esprimo D9500 M9400 U9200
GB-FK7600	Fujitsu-SiemensAmilo K7600 Series; Advent Gericom Mitac MiNote 8089, 8089P, 8389, 8889 Se
GB-FK7600H	Fujitsu-SiemensAmilo K7600 Series; Advent Gericom Mitac MiNote 8089, 8089P, 8389, 8889 Se
GB-FM1010	FUJITSU LifeBook M1010 FUJITSU-SIEMENS Amilo Mini Ui 3520
GB-FM1420	Fujitsu-Siemens Amilo L / M (BP-8050) Fujitsu-Siemens Amilo M1420 Fujitsu-Siemens Amilo L1300 Fujitsu-Siemens Amilo C1300GC FUJITSU Amilo M1420 FUJITSU Amilo M-1420 FUJITSU Amilo L1310G FUJITSU Amilo L1310 FUJITSU Amilo L1300 FUJITSU Amilo L 1310G
GB-FM1420H	Fujitsu-Siemens Amilo L / M (BP-8050) Fujitsu-Siemens Amilo M1420 Fujitsu-Siemens Amilo L1300 Fujitsu-Siemens Amilo C1300GC FUJITSU Amilo M1420 FUJITSU Amilo M-1420 FUJITSU Amilo L1310G FUJITSU Amilo L1310 FUJITSU Amilo L1300 FUJITSU Amilo L 1310G
GB-FP2530	Amilo Pi2530 Pi2550 Pi3540 Series; Amilo Xi2428 Xi2550 Xi2530 Series;
GB-FSL7300	Fujitsu-SiemensAmilo L7300Amilo
GB-FT2020	Fujitsu LifeBook T2020 Tablet PC

Battery

GB-FT2020H	Fujitsu LifeBook T2020 Tablet PC
GB-FV2000	FUJITSU-SIEMENS Amilo M7400, M7000 , Amilo Pro V2000 Series
	Aopen Barebook 1555, 1555A, 1555G, 1556, 1556A, 1556G, 1556J, 1556O, 1557, 1557A, 1557G, 1557J Series
	Maxdata Pro 7000x Series
	LIFETEC Coris 690, Coris Z71 Series
	Wortmann Terra Aura, M800
GB-FV2030	Fujitsu Siemens Amilo Pro V2030 V2035 V2055
GB-FV3505	Fujitsu-siemens Amilo V3405, V3505, V3525, V8210 Series ESPRIMO Mobile V5545, V6535ESPRIMO Mobile V5505, ESPRIMO Mobile V5545, ESPRIMO Mobile V6505, ESPRIMO Mobile V6535, ESPRIMO Mobile V6545, ESPRIMO Mobile V6555
GB-FV5535	Fujitsu-Siemens V5515 V5535 Series
GB-FV5535H	FUJITSU ESPRIMO Mobile V5535 Battery FUJITSU-SIEMENS FUJITSU-SIEMENS ESPRIMO Mobile V5515 Battery FUJITSU-SIEMENS ESPRIMO Mobile V5535 Battery FUJITSU-SIEMENS ESPRIMO Mobile V5555 Battery
GB-FX3530	Fujitsu Siemens Amilo XA3530 Fujitsu Siemens Amilo XA3533 Fujitsu Siemens Amilo PA3515 Fujitsu Siemens Amilo PA3553 Fujitsu Siemens Amilo PA3530
GB-FX3670	Fujitsu Siemens Amilo Xi3650 Xi3670 Pi3625 Series
GB-FX9510	FUJITSU ESPRIMO MOBILE X9510, X9515, X9525

Battery

GB-CX200 Gateway CX200
Gateway CX200S
Gateway CX200X
Gateway CX210
Gateway CX210S
Gateway CX210X
Gateway CX2608
Gateway CX2610
Gateway CX2615
Gateway CX2618
Gateway CX2619
Gateway CX2620
Gateway CX2620H
Gateway CX2720
Gateway CX2724
Gateway CX2726
Gateway M280

Gat
GB-CX200 Gateway CX200
Gateway CX200S
Gateway CX200X
Gateway CX210
Gateway CX210S
Gateway CX210X
Gateway CX2608
Gateway CX2610
Gateway CX2615
Gateway CX2618
Gateway CX2619
Gateway CX2620
Gateway CX2620H
Gateway CX2720
Gateway CX2724
Gateway CX2726
Gateway M280
Gat

Battery

GB-CX200H	Gateway CX200 Gateway CX200S Gateway CX200X Gateway CX210 Gateway CX210S Gateway CX210X Gateway CX2608 Gateway CX2610 Gateway CX2615 Gateway CX2618 Gateway CX2619 Gateway CX2620 Gateway CX2620H Gateway CX2720 Gateway CX2724 Gateway CX2726 Gateway M280 Gat
GB-G3000	Gateway: Gateway S-7000N, Gateway S-7200N, Gateway W322 Gateway 3000GZ Series Gateway 3000 Series 3018GZ, 3040GZ, 3610GZ Gateway 3500 Series 3520GZ, 3522GZ, 3525GB, 3545GZ, 3550GH, 3550GZ Gateway M210 Series Gateway M250 Series M250A, M250B, M250
GB-G4000	Gateway 4000 Series 4012GZ, 4024GZ, 4025GZ, 4026GZ, 4028GZ, 4028JP, 4030GH, 4030GZ, 4520GZ, 4525GZ, 4530GH, 4530GZ, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 4541BZ, 4542GP, 4543BZ Gateway M300 Series M320, M325

Battery

GB-G4000H	Gateway 4000 Series 4012GZ, 4024GZ, 4025GZ, 4026GZ, 4028GZ, 4028JP, 4030GH, 4030GZ, 4520GZ, 4525GZ, 4530GH, 4530GZ, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 4541BZ, 4542GP, 4543BZ
	Gateway M300 Series M320, M325
GB-G450	Gateway 400/450 seriesGateway Laptop: 400VTX
	Gateway Laptop: 450E 450RGH 450ROG 450SP 450SX4 450X 450XL
GB-G450	Gateway 400/450 seriesGateway Laptop: 400VTX
	Gateway Laptop: 450E 450RGH 450ROG 450SP 450SX4 450X 450XL
GB-G6000	Gateway6000/8000/S-7500N/ MX8000/MX6400/MX6440 series
GB-G6000H	Gateway6000/8000/S-7500N/ MX8000/MX6400/MX6441 series
GB-G6800	T-6800 Series, M-150, M-1400, M-1600, M6300, M6700, M-6800, P-170, P-6300, T-1600, T6300
GB-G6800H	T-6800 Series, M-150, M-1400, M-1600, M6300, M6700, M-6800, P-170, P-6300, T-1600, T6300
GB-G7210	Gateway: Gateway 7000GX Series 7110GX, 7210GX, 7215GX, 7405GX, 7410GX, 7415GX, 7422GX, 7426GX, 7508GX, 7510GX
	Gateway 7000GZ Series 7305GZ, 7320GZ, 7322GZ, 7324GZ, 7325GZ, 7326GZ, 7330GZ
	Gateway 7000 Series 7000S, 7210, 7215, 7305, 7310MX, 7312MX, 73
GB-G9500	Gateway Notebook Battery Solo 9500 and 9550 series
GB-GM210	M210, M250, 3000 series
	Gateway M210 Notebook - 1008255 Gateway M250 Notebook - 2900782 Gateway M250A Notebook - 2900807 Gateway M250B Notebook - 2900808 Gateway M250E Notebook - 1008469 Gateway M250GS Notebook - 1008476 Gateway M250ES Notebook -

Battery

GB-GM210H	M210, M250, 3000 series Gateway M210 Notebook - 1008255 Gateway M250 Notebook - 2900782 Gateway M250A Notebook - 2900807 Gateway M250B Notebook - 2900808 Gateway M250E Notebook - 1008469 Gateway M250GS Notebook - 1008476 Gateway M250ES Notebook -
GB-GM275	Gateway M275 /M275R
GB-GM275	Gateway M275 /M275R
GB-GM500	Gateway Solo M500 & M505, Medion MD2900 MD6179 series
GB-GM675	Gateway LGA-M675 , 6500839 , 6500853 4UR18650F-3-QC-PA1, PA1 4SP3 , SQU-301
GB-GM675H	Gateway LGA-M675 , 6500839 , 6500853 4UR18650F-3-QC-PA1, PA1 4SP3 , SQU-301
GB-GN4400	Gateway NV4001, NV4001C, NV4005C, NV4400, NV4402C, NV4406C, NV4803C, NV4808C, NV4809C, NV4810C, NV4811C
GB-GE1720	Gericom Bellagio 1720, Bellagio Evolution, Webshox 2, Webshox Per4mance Systemax Pursuit 2100, Pursuit SV, Pursuit SV2, Pursuit SV3
GB-Hi3090	Hitachi Mx series
GB-H110	Mini 110Mini 110 Mi EditionMini 110 XP EditionMini 1101Mini 110-1000Mini 110-1001TUMini 110-1006TUMini 110-1007TUMini 110-1008TUMini 110-1011TUMini 110-1012NRMini 110-1013TUMini 110-1014TUMini 110-1015LAMini 110-1016TUMini 110-1017TUMini 110-1019TUMini 11
GB-H110H	Mini 110Mini 110 Mi EditionMini 110 XP EditionMini 1101Mini 110-1000Mini 110-1001TUMini 110-1006TUMini 110-1007TUMini 110-1008TUMini 110-1011TUMini 110-1012NRMini 110-1013TUMini 110-1014TUMini 110-1015LAMini 110-1016TUMini 110-1017TUMini 110-1019TUMini 11

Battery

GB-H1800	Presario 1247 Presario 12XL501 Presario 1232ES Presario 1200EA-470016-816 Presario 1232 Presario 1244 Presario 12XL204 Presario 1217JP Presario 1200EA Presario 1215 Presario 1216 Presario 1214EA Presario 1200AP-470016-373 Presario 1200AP Pre HP
GB-H2100	HP Omnibook 2100 Series OmniBook 2100, OmniBook 2103, OmniBook 2104, OmniBook 2105, OmniBook 2106, OmniBook 2120, OmniBook 2121, OmniBook 2122, OmniBook 2123, OmniBook 2124, OmniBook 2125, OmniBook 2126, OmniBoo
GB-H2133	HP 2133 Mini-Note Laptop
GB-H2133H	HP 2133 Mini-Note Laptop
GB-H2133H	HP 2133 Mini PC series HP 2133 Mini-Note PC KE948UT, HP 2133 Mini-Note PC KR954UT HP 2133 Mini-Note PC KR939UT, HP 2133 Mini-Note PC KX868AT HP 2133 Mini-Note PC KR922UT, HP 2133 Mini-Note PC KX869AT HP 2133 Mini-Note PC KR922UT
GB-H2710	HP Compaq 2133 Mini PC se HP Business Notebook 2710p
GB-H3000	Compaq Compaq Presario 3000 Series
GB-H311	HP Mini 311, 311c series
GB-H311H	HP Mini 311, 311c series
GB-H3500	Armada 3500
GB-H4100	HP OmniBook 4100 Series OmniBook 4100, OmniBook 4101, OmniBook 4102, OmniBook 4103, OmniBook 4104, OmniBook 4105, OmniBook 4106, OmniBook 4107, OmniBook 4108, OmniBook 4110, OmniBook 4111, OmniBook 4150, OmniBoo
GB-H4416	HP 4416S HP 4411S
GB-H4710	ProBook 4510s, ProBook 4510s/CT, ProBook 4515s, ProBook 4515s/CT, ProBook 4710s, ProBook 4710s/CT

Battery

GB-H500	OMNIBOOK 500HP OmniBook 500, 500B, 510, Pavilion xu155, zu175, zu1155, zu1175 series
GB-H5000	Compaq LTE 5000 Series LTE 5000, LTE 5000CD, LTE 5000CX, LTE 5030, LTE 5080, LTE 5100, LTE 5150, LTE 5180, LTE 5200, LTE 5230, LTE 5250, LTE 5280, LTE 5300, LTE 5380, LTE 5400, LTE 5500
GB-H510	HP 510, 530 sreies notebooks
GB-H5101	HP MINI 5101
GB-H510H	HP 510, 530 sreies notebooks
GB-H520	HP 520
GB-H5310	HP Probook 5310m Series
GB-H6000	Omnibook/Pavilion 6000/6100/VT6200/XT6050 Panasonic CGR-B/650AE CGR-B/ 634AE 3UR18650F-2-QC-RT2 3UR18650P-2-QC-RT
GB-H6520	HP 6520 series HP6520S series
GB-H6520H	HP 6520 series HP6520S series
GB-H6530	HP Compaq 6530b, Compaq 6535b, Compaq 6730b, Compaq 6735b
GB-H6530	HP Compaq 6530b, Compaq 6535b, Compaq 6730b, Compaq 6735b
GB-H6700	HP Compaq 6700 Series, HP Compaq 6730 Series, Compaq 6720 Compaq 6720s, Compaq 6820, Compaq 6820S
GB-H6700	HP Compaq 6700 Series, HP Compaq 6730 Series, Compaq 6720 Compaq 6720s, Compaq 6820, Compaq 6820S
GB-H6700H	HP Compaq 6700 Series, HP Compaq 6730 Series, Compaq 6720 Compaq 6720s, Compaq 6820, Compaq 6820S
GB-H6700H	HP Compaq 6700 Series, HP Compaq 6730 Series, Compaq 6720 Compaq 6720s, Compaq 6820, Compaq 6820S
GB-H7300	Compaq Armada 7300 Series Armada 7300, Armada 7330 (273150-004), Armada 7330MT, Armada 7330T, Armada 7350, Armada 7350 (273160-004, 273162-004), Armada 7350DMT, Armada 7350MT, Armada 7360, Armada 7360 (305900-005),
GB-H7400	Amarda 7400

Battery

GB-H7700	Compaq Armada 7700 Series
GB-H7800	Compaq Amarda 7800 series
GB-H8530	EliteBook 8530p, EliteBook 8530w, EliteBook 8730p, EliteBook 8730w
GB-HB1200	HP Compaq Presario B1200 Series HP Compaq Presario B1216TU, Compaq Presario CQ20 Series, HP BUSINESS NOTEBOOK 2230S HP Compaq Presario B1217TU, HP Compaq Presario B1200 HP Compaq Presario B1234TU, HP Compaq Presario B1235TU, HP Compaq Presario B1236T
GB-HB1200H	HP Compaq Presario B1200 Series HP Compaq Presario B1216TU, Compaq Presario CQ20 Series, HP BUSINESS NOTEBOOK 2230S HP Compaq Presario B1217TU, HP Compaq Presario B1200 HP Compaq Presario B1234TU, HP Compaq Presario B1235TU, HP Compaq Presario B1236T
GB-HB1800	Presario B1800/NX4300
GB-HB1800H	Presario B1800/NX4300
GB-HB1900	HP Compaq Presario B1900 Series HP Compaq Presario B1903TU HP Compaq Presario B1904TU HP Compaq Presario B1905TU HP Compaq Presario B1952TU HP Compaq Presario B1953TU HP Compaq Presario B1954TU HP Compaq Presario B1921TU HP Compaq Presario B1923TU HP
GB-HB1900H	HP Compaq Presario B1900 Series HP Compaq Presario B1903TU HP Compaq Presario B1904TU HP Compaq Presario B1905TU HP Compaq Presario B1952TU HP Compaq Presario B1953TU HP Compaq Presario B1954TU HP Compaq Presario B1921TU HP Compaq Presario B1923TU HP
GB-HB3800	HP Compaq Presario B3800 Series
GB-HC700	Compaq Armada110 C700/C800/110 P800/110S 800/N110/110 850//110 PIII 800

Battery

GB-HDM3	Pavilion dm3 Pavilion dm3-1001au Pavilion dm3-1014tu Pavilion dm3-1032tx Pavilion dm3-1001ax Pavilion dm3-1014tx Pavilion dm3-1033tx Pavilion dm3-1001tu Pavilion dm3-1015ax Pavilion dm3-1034tx Pavilion dm3-1002ax Pavilion dm3-1015eo Pavilion dm3-1035br Pa
GB-HDV1000	HP Compaq Business Notebook Series nx4800, nx7100, nx7200 Compaq Presario M2000 Series M2000-PK550AV, M2000-PK551AV, M2000-PQ660AV, M2001AP-PS929PA, M2001AL-EA130PC, M2001EA-PS744EA, M2001-PT591AS, M2002AL-EA1
GB-HDV1000H	HP Compaq Business Notebook Series nx4800, nx7100, nx7200 Compaq Presario M2000 Series M2000-PK550AV, M2000-PK551AV, M2000-PQ660AV, M2001AP-PS929PA, M2001AL-EA130PC, M2001EA-PS744EA, M2001-PT591AS, M2002AL-EA1
GB-HDV1000H	HP Compaq Business Notebook Series nx4800, nx7100, nx7200 Compaq Presario M2000 Series M2000-PK550AV, M2000-PK551AV, M2000-PQ660AV, M2001AP-PS929PA, M2001AL-EA130PC, M2001EA-PS744EA, M2001-PT591AS, M2002AL-EA1
GB-HDV2	HP DV2 Series /
GB-HDV2000	HP HP Pavilion dv2500t, HP Pavilion dv6500t HP Pavilion dv2000 Series Pavilion dv2000T, Pavilion dv2000Z, Pavilion dv2001TU, Pavilion dv2001TX, Pavilion dv2001XX, Pavilion dv2002TU, Pavilion dv2002TX, Pavilion dv200
GB-HDV2000H	HP HP Pavilion dv2500t, HP Pavilion dv6500t HP Pavilion dv2000 Series Pavilion dv2000T, Pavilion dv2000Z, Pavilion dv2001TU, Pavilion dv2001TX, Pavilion dv2001XX, Pavilion dv2002TU, Pavilion dv2002TX, Pavilion dv200

Battery

GB-HDV2000H	HP HP Pavilion dv2500t, HP Pavilion dv6500t HP Pavilion dv2000 Series Pavilion dv2000T, Pavilion dv2000Z, Pavilion dv2001TU, Pavilion dv2001TX, Pavilion dv2001XX, Pavilion dv2002TU, Pavilion dv2002TX, Pavilion dv200
GB-HDV2H	HP DV2 Series /
GB-HDV3	HP DV3 Series
GB-HDV3000	HP Compaq DV3000 series
GB-HDV3000H	HP Compaq DV3000 series
GB-HDV3H	HP DV3 Series
GB-HDV4	Compaq Presario CQ40 series Compaq Presario CQ45 series Compaq Presario CQ50 series Compaq Presario CQ60 series Compaq Presario CQ70 series HP HDX: HDX 16 series HP DV4 series HP DV4-1000 series HP DV4-1100 series HP DV4-1200 series HP DV5 serie
GB-HDV4H	Compaq Presario CQ40 series Compaq Presario CQ45 series Compaq Presario CQ50 series Compaq Presario CQ60 series Compaq Presario CQ70 series HP HDX: HDX 16 series HP DV4 series HP DV4-1000 series HP DV4-1100 series HP DV4-1200 series HP DV5 serie
GB-HDV4H	Compaq Presario CQ40 series Compaq Presario CQ45 series Compaq Presario CQ50 series Compaq Presario CQ60 series Compaq Presario CQ70 series HP HDX: HDX 16 series HP DV4 series HP DV4-1000 series HP DV4-1100 series HP DV4-1200 series HP DV5 serie
GB-HDV7	Pavilion DV7 seriesDV7T, DV7Z, DV7-1000, DV2700

Battery

GB-HDV7	Pavilion DV7 seriesDV7T, DV7Z, DV7-1000, DV2700
GB-HDV7H	Pavilion DV7 seriesDV7T, DV7Z, DV7-1000, DV2700
GB-HDV7H	Pavilion DV7 seriesDV7T, DV7Z, DV7-1000, DV2700
GB-HDV8000	HP HP Pavilion 8099 HSTNN-IB20 HP Pavilion dv8000 Series Pavilion dv8000t, Pavilion dv8000z, Pavilion dv8002ea, Pavilion dv8005ea, Pavilion dv8010ea, Pavilion dv8013cl, Pavilion dv8013xx, Pavilion dv80xxus
GB-HDV8000H	HP HP HP Pavilion dv8000 Series Pavilion dv8000t, Pavilion dv8000z, Pavilion dv8002ea, Pavilion dv8005ea, Pavilion dv8010ea, Pavilion dv8013cl, Pavilion dv8013xx, Pavilion dv80xxus HP Pavilion dv8100 Series
GB-HDV9000	DV9000 Series DV9000T DV9000Z DV9009 DV9039 DV9040 DV9060 HP Pavilion DV9000 CTO EW635AV DV9000t CTO, EZ379AV DV9000z CTO EW680AV DV9005 DV9005US DV9005CA EZ452UA EZ461UA DV9008 DV9008NR EZ458UA, DV9009 DV9009US DV9009NR DV9009CL EZ459UA EZ468UA EZ470UA D
GB-HDV9000H	DV9000 Series DV9000T DV9000Z DV9009 DV9039 DV9040 DV9060 HP Pavilion DV9000 CTO EW635AV DV9000t CTO, EZ379AV DV9000z CTO EW680AV DV9005 DV9005US DV9005CA EZ452UA EZ461UA DV9008 DV9008NR EZ458UA, DV9009 DV9009US DV9009NR DV9009CL EZ459UA EZ468UA EZ470UA D
GB-HE500	Compaq Armada V300 Series Compaq Armada V500 Series Compaq Armada E500 Series Armada E500, Armada E500S
GB-HE500H	Armada E500/E500S/V500/V300/pp2026 Series
GB-HE700	Armada E700 Series
GB-HM1000	HP Mini 1000 10.2 " all series HP Mini 1000, HP Mini 1001, HP Mini 1014, HP Mini 1010NR, HP Mini 1035NR, HP Mini 1050 Compaq mini 700
GB-HM1000H	HP Mini 1000 10.2 " all series HP Mini 1000, HP Mini 1001, HP Mini 1014, HP Mini 1010NR, HP Mini 1035NR, HP Mini 1050 Compaq mini 700
GB-HM300	Compaq Compaq Armada M300 Series, Compaq Presario 300 Series, Compaq Presario 305 Series

Battery

GB-HM300H	Compaq Compaq Armada M300 Series, Compaq Presario 300 Series, Compaq Presario 305 Series
GB-HM700	Armada M700/170
GB-HN100	Evo N100, N160/Presario 1700/1500 series
GB-HN105	Compaq EVO N105/N115/Presario1400/ Compaq Presario 700 SeriesP700/700US/700Z/705/705US/710/711CL/715/720US/721CL/ 722US/723RSH/725/725US/730US/732US
GB-HN150	Compaq n150, 244388-b25, 231962-001, 232060-001 244388-B25 PP2110, PP2111X
GB-HN180	Presario 2700/2700T/N180 Series
GB-HN400	Compaq EVO N400 Series, Compaq EVO N400c Series, Compaq EVO N410 Series, Compaq EVO N410c Series
GB-HN600	Evo N600/Evo N600c/Evo N610c/Evo N610v/Evo N620c
GB-HNC2400	Business Notebook nc2400/ 2400 /2510P Series
GB-HNC2400H	Business Notebook nc2400/ 2400 /2510P Series
GB-HNC2400H	Business Notebook nc2400/ 2400 /2510P Series
GB-HNC4000	NC4000/NC4010 Series
GB-HNC4200	NC4200/NC4400/TC4200/TC4400
GB-HNC6000	Notebook NC6000/NC8000/NW8000/NX5000/ Series
GB-HNC6400	NC6400//NX510/0NC6105/NC6100/NC6110/NC6115/NC6120/NC61 40/NC6200/NC6200/NC6220/NC6230/NX6100/NX6105/NX6110/NX6 110/CT/NX6115/NX6120/NX6125/NX6130/NX6140/NX6300/NX6310 /NX6310/CT/NX6315/NX6320/NX6320/CT/NX6325
GB-HNC6400H	NC6400//NX510/0NC6105/NC6100/NC6110/NC6115/NC6120/NC61 40/NC6200/NC6200/NC6220/NC6230/NX6100/NX6105/NX6110/NX6 110/CT/NX6115/NX6120/NX6125/NX6130/NX6140/NX6300/NX6310 /NX6310/CT/NX6315/NX6320/NX6320/CT/NX6325
GB-HNC8200	HP Compaq Business Notebook nc8430 Business Notebook 8400 Series Business Notebook 8510w Business Notebook nx8420 Business Notebook nx7400 Business Notebook nw8240 Business Notebook nc8230 Business Notebook 8200 Series Business Notebook 8710p Bu
GB-HNC8200	HP Compaq Business Notebook nx7300 Business Notebook nx7400 Series

Battery

GB-HNC8200H	HP Compaq Business Notebook nc8430 Business Notebook 8400 Series Business Notebook 8510w Business Notebook nx8420 Business Notebook nx7400 Business Notebook nw8240 Business Notebook nc8230 Business Notebook 8200 Series Business Notebook 8710p Bu
GB-HNC8200H	HP Compaq Business Notebook nc8430 Business Notebook 8400 Series Business Notebook 8510w Business Notebook nx8420 Business Notebook nx7400 Business Notebook nw8240 Business Notebook nc8230 Business Notebook 8200 Series Business Notebook 8710p Bu
GB-HNX9010	Compaq BUSINESS NOTEBOOK NX9000 SERIES , PRESARIO 100CA , PRESARIO 2100 , PRESARIO 2100 SERIES , PRESARIO 2100AP , PRESARIO 2100CA , PRESARIO 2100LA , PRESARIO 2100US , PRESARIO 2101AP , PRESARIO 2101US , PRESARIO 2102AP , PRESARIO 2102EA , PRESARIO 2102U
GB-HR3000	Compaq Compaq Presario R4225CA Compaq Presario R3000 Series Presario R3000AP (DV799#ABS) Business Notebook NX9110 Series nx9110 (DV102u#ABA) HP Compaq HP PP2200 Series HP PP2210 Series HP Business N

Battery

GB-HR3000H	Compaq Compaq Presario R4225CA Compaq Presario R3000 Series Presario R3000AP (DV799#ABS) Business Notebook NX9110 Series nx9110 (DV102u#ABA) HP Compaq HP PP2200 Series HP PP2210 Series HP Business N
GB-HTC1000	Compaq Compaq Tablet PC TC100 Compaq Tablet PC TC1000 Series Tablet PC TC1000 (DG985A), Tablet PC TC1000 (DL990A), Tablet PC TC1000 (470044-783), Tablet PC TC1000 (470044-784), Tablet PC TC1000 (470044-785), Tablet PC TC1
GB-HTX1000	HP Compaq Pavilion tx1100/TX1106AU, TX1150EA, tx1125ea, tx1129ea, tx1137ea, tx1100, tx1101au, tx1102au, tx1103au, tx1104au, tx1105AU, tx1126ea, tx1127ea, tx1128ea, tx1138ea, tx1140ea, tx1151ea/tx1200, TX1240EF, TX1250EO, TX1250ES, TX1270ED, TX1270EO, TX12
GB-HTX1000H	HP Compaq Pavilion tx1100/TX1106AU, TX1150EA, tx1125ea, tx1129ea, tx1137ea, tx1100, tx1101au, tx1102au, tx1103au, tx1104au, tx1105AU, tx1126ea, tx1127ea, tx1128ea, tx1138ea, tx1140ea, tx1151ea/tx1200, TX1240EF, TX1250EO, TX1250ES, TX1270ED, TX1270EO, TX12
GB-HTX1000H	HP Compaq Pavilion tx1100/TX1106AU, TX1150EA, tx1125ea, tx1129ea, tx1137ea, tx1100, tx1101au, tx1102au, tx1103au, tx1104au, tx1105AU, tx1126ea, tx1127ea, tx1128ea, tx1138ea, tx1140ea, tx1151ea/tx1200, TX1240EF, TX1250EO, TX1250ES, TX1270ED, TX1270EO, TX12
GB-HX1000	HP Compaq HP Compaq Business Notebook nx7000 Series Business Notebook nx7000, Business Notebook nx7010 Compaq Compaq Presario X1000 Series Presario X1000, Presario X1000 (DE185AV), Presario X1000 (DE186AV)
GB-HX9000	HP Pavilion HDX9000 HDX9100 HDX9200 HDX9300 HDX9400 HDX9500 Entertainment Series

Battery

GB-HXE2	<p>HP</p> <p>HP Pavilion N3000 -F1920A, HP Pavilion N3380-F1930A</p> <p>HP Omnibook XE Series, HP Omnibook XE2 Series, HP Omnibook XE2-DA Series, HP Pavilion N3100 Series, HP Pavilion N3200 Series, HP Pavilion N3300 Series, HP Pavi</p>
GB-HXE3	Omnibook Xe3/GD/Pavilion N5000/N52XX/N5300/N54XX series
GB-HXE3H	Omnibook Xe3/GD/Pavilion N5000/N52XX/N5300/N54XX series
GB-HXT1000	OmniBook XT1000 Series- F3434H, F3434J, F3442H, F3442J, F3443H, F3443J, F3422H, F3428H, F5551H, F5646HS, F3419H, F3429HT, F3429H, F3430HR, F3430H, F3431H, F3432H, F3433HT, F3433H, F3440H, F3440J, F3441H, F3441J, F4724HS, F4724H, F4755HS, F4759HS, F4760HS,
GB-HZD7000	ZD7000/zd7000 CTO /ZD7001EA/ZD7001US/zd7005ea//ZD7005US/zd7009ea/zd7010ca/zd7010ea/ZD7010QV/ZD7010US/zd7012ea/ZD7015EA/zd7015us/zd7020ea/zd7020us/zd7030ea/zd7035ea/ZD7038/zd7038ea/ZD7040EA/ZD7040US/zd7045ea/zd7048cl/zd7048ea/zd7049ea/zd7050ea
GB-I1200	ThinkPad i1100/i1100/i1161/i1171/i1200/i1200/i1210/i1211/i1241/i1251/i1271/i1300 Series ThinkPad i1300/i1321/i1340/i1351/i1361/i1391/i2621 Series
GB-I1300	ThinkPad 1300 series
GB-I1400	ThinkPad IBM ThinkPad i1400/1500500/501/501DX/502/502DX/502T/503/503T/505/507/508
GB-I1400H	ThinkPad IBM ThinkPad i1400/1500500/501/501DX/502/502DX/502T/503/503T/505/507/508
GB-I240	Thinkpad 240/240X Series
GB-I240H	Thinkpad 240/240X Series
GB-I360	ThinkPad 355, 360, 360C series
GB-I365	ThinkPad 365 series
GB-I370	ThinkPad 370, 750, 755C series (Intelligent)
GB-I380	ThinkPad 380/380CE/380CS/380CSE/380D/380D-MMX/380E/380ED/380X/380XD/380Z/385/385CD/385D/385D-MMX/385E/385ED/385XD
GB-I390	ThinkPad i1700/i1720/i1721/390X/390/390E series
GB-I390H	ThinkPad i1700/i1720/i1721/390X/390/390E series

Battery

GB-I410	Lenovo IBM ThinkPad 410M, 410, 125, E280, E660, E680 SQU-504 Advent 7000 Advent 7087 LE1 notebooks
GB-I560	ThinkPad 560/560C/560E/560X/560Z Series
GB-I570	ThinkPad570/570E/570Z Series
GB-I600	ThinkPad 600/600D/600E/600X/600X 2645-5EU notebook
GB-I701C	ThinkPad 701C series/ (Intelligent)
GB-I760	ThinkPad 755CD/760CD/760C series
GB-I770	ThinkPad 770/770 9548-XXX/770 9549-XXX/770D/770E/770E 9548- XXX/770E 9549-XXX/770ED/770ED 9548-XXX/770ED 9549- XXX/770U/770X/770X 9544-XXX/770X 9549-XXX/770Z/770Z 9544- XXX/770Z 9549-XXX
GB-IA20	ThinkPad A20/A20/A20M/A20P/A2/A21M/A21P/A22M/A22P
GB-IA20H	ThinkPad A20/A20/A20M/A20P/A2/A21M/A21P/A22M/A22P
GB-IA21E	Think Pad A21E/A22E Series
GB-IA30	ThinkPad A30/A30P/A31/A31P/A30 series
GB-IC100	Lenovo C100 Series
GB-IC430	Lenovo C430 C430A C430M FRU 121SM000Q battery
GB-IE600	Lenovo E600 Battery Lenovo A500 Battery
GB-IF30	Lenovo F30, F30A, F31, F31A Series QUANTA CW3 Series
GB-IG230	3000 G2303000 G230 200063000 G230 41073000 G230G
GB-IG40	ThinkPad G40/G40-2384/G40-2387/G40-2388/G40-2389/G41 Series/G41-2881
GB-IG400	C460 C510 G400Series 3000 G400 59011 3000 G410 Series 3000 G400 14001 3000 G400 2048 3000 G400 Series
GB-IG40H	ThinkPad G40/G40-2384/G40-2387/G40-2388/G40-2389/G41 Series/G41-2881
GB-IG530	3000 G430 Series, 3000 G530 Series, 3000 N500 Series, IdeaPad G430 Series
GB-IL510	Lenovo IBM ThinkPad SL410 SL510
GB-IN100	3000 N100 0768 3000 C200 8922 3000 N100 0689 3000 N100 Series 3000 C200 Series
GB-IN100H	3001 N100 0768 3000 C200 8922 3000 N100 0689 3000 N100 Series 3000 C200 Series

Battery

GB-IN200	Lenovo N200 Series (14" Wide screen)
GB-IR30	Thinkpad R30/R31 Series
GB-IR40	Thinkpad R32/R40 Series
GB-IR40E	ThinkPad R40e/2685/R40e/2684
GB-IR61	IBM-Lenovo ThinkPad R61 14-Inch Wide IBM-Lenovo ThinkPad R61-7732 IBM-Lenovo ThinkPad R61-7733 IBM-Lenovo ThinkPad R61-7734 IBM-Lenovo ThinkPad R61-7735 IBM-Lenovo ThinkPad R61-7736 IBM-Lenovo ThinkPad R61-7737 IBM-Lenovo ThinkPad R61-7738 IBM-Lenovo Thin
GB-IR61H	R61 Series(14-inch wide), T61 Series(14-inch wide)
GB-IR61H	R61 Series(14-inch wide), T61 Series(14-inch wide)
GB-IS10	Lenovo IdeaPad S9/S10 Series
GB-IS10H	Lenovo IdeaPad S9/S10 Series
GB-IS10H	Lenovo IdeaPad S9/S10 Series
GB-IS620	Lenovo S620 Series
GB-IT20	Think Pad T20/T20 2647-XXX/T20 2648-XXX/T21/T21 2647-XXX/T21 2648-XXX/T22/T22 2647-XXX/T22 2648-XXX/T23/T23 2647-XXX/T23 2648-XXX
GB-IT30	Think Pad T30 Series
GB-IT40	ThinkPad T40P/T41T41/T41P/T42/T42P/T43/T43P/R50/R50E/R50P/R51/R52 Series
GB-IT40H	ThinkPad T40P/T41T41/T41P/T42/T42P/T43/T43P/R50/R50E/R50P/R51/R52 Series
GB-IT60	ThinkPad T60/R60/Z60m 2529/Z60m 2530/Z60m 2531/Z60m 2532/Z60m Series /Z61e/Z61e 0762/ThinkPad Z61e 0763/Z61e 0764/Z61e 09450/Z61e 09451/Z61e 09452/Z61e 09453/Z61m/Z61m 0672/Z61m 0673/Z61m 0674/Z61m 9450/Z61m 9451/Z61m 9452/Z61m 9453
GB-IT60H	ThinkPad T60/R60/Z60m 2529/Z60m 2530/Z60m 2531/Z60m 2532/Z60m Series /Z61e/Z61e 0762/ThinkPad Z61e 0763/Z61e 0764/Z61e 09450/Z61e 09451/Z61e 09452/Z61e 09453/Z61m/Z61m 0672/Z61m 0673/Z61m 0674/Z61m 9450/Z61m 9451/Z61m 9452/Z61m 9453
GB-IT60H	ThinkPad T60/R60/Z60m 2529/Z60m 2530/Z60m 2531/Z60m 2532/Z60m Series /Z61e/Z61e 0762/ThinkPad Z61e 0763/Z61e 0764/Z61e 09450/Z61e 09451/Z61e 09452/Z61e 09453/Z61m/Z61m 0672/Z61m 0673/Z61m 0674/Z61m 9450/Z61m 9451/Z61m 9452/Z61m 9453
GB-IU110	IdeaPad U110 11306, IdeaPad U110 2304, IdeaPad U110 Series
GB-IU110H	IdeaPad U110 11306, IdeaPad U110 2304, IdeaPad U110 Series
GB-IU350	Lenovo IdeaPad U350 Series, IdeaPad U350W
GB-IV100	V100, V200
GB-IV30	Lenovo V30, V31, V32, E200, Y160, S3 series
GB-IV60	Lenovo V60 V66 V68 V80 E420 A800 Series

Battery

GB-IW700	ThinkPad W700 Laptop battery
GB-IX20	Think pad X20/X20 2660-XXX/X20 2661-XXX/X20 2662-XXX/X21/X21 2660-XXX/X21 2662-XXX/X22/ X22 2660-XXX/X22 2662-XXX/X23/X23 2660-XXX/X23 2662-XXX/X24/X24 2660-XXX /X24 2662-XXX/X SERIES
GB-IX200	IBM Lenovo ThinkPad X200 Series Lenovo ThinkPad X200S Series
GB-IX200H	IBM Lenovo ThinkPad X200 Series Lenovo ThinkPad X200S Series
GB-IX200T	IBM Lenovo ThinkPad X200T Series
GB-IX30	Thinkpad X30/X31 Series
GB-IX300	IBM Lenovo ThinkPad X300 Series Lenovo ThinkPad X300S Series
GB-IX300	IBM Lenovo ThinkPad X300 Series Lenovo ThinkPad X300S Series
GB-IX300H	IBM Lenovo ThinkPad X300 Series Lenovo ThinkPad X300S Series
GB-IX30H	Thinkpad X30/X31 Series
GB-IX40	Thinkpad X40/X41
GB-IX40H	Thinkpad X40/X41
GB-IX41T	X41T
GB-IX60	ThinkPad X60s Series/X60s 1702/X60s 1703/X60s 1704/X60s 1705/X60s 2507, ThinkPad X60s 2508, ThinkPad X60s 2533/X60 1706/X60 1707/X60 1708/X60 1709/X60 2509/X60 2510
GB-IX60H	ThinkPad X60s Series/X60s 1702/X60s 1703/X60s 1704/X60s 1705/X60s 2507, ThinkPad X60s 2508, ThinkPad X60s 2533/X60 1706/X60 1707/X60 1708/X60 1709/X60 2509/X60 2510
GB-IX60H	ThinkPad X60s Series/X60s 1702/X60s 1703/X60s 1704/X60s 1705/X60s 2507, ThinkPad X60s 2508, ThinkPad X60s 2533/X60 1706/X60 1707/X60 1708/X60 1709/X60 2509/X60 2510
GB-IX61	ThinkPad X60 Tablet PC 6363, ThinkPad X60T Tablet PC 6364, ThinkPad X60 Tablet PC 6365, ThinkPad X60 Tablet PC 6366, ThinkPad X60 Tablet PC 6367, ThinkPad X60 Tablet PC 6368
GB-IY100	Lenovo Y100 Series Lenovo F40, F41, F50 V100 Series
GB-IY100H	Lenovo Y100 Series Lenovo F40, F41, F50 V100 Series
GB-IY300	Y3003000 Y300 7759 3000 Y300 9449 3000 Y300 9454 3000 Y310 3000 Y310 7756 3000 Y310a 3000 Y310a 7756
GB-IY330	Lenovo Lenovo IdeaPad U330 Series IdeaPad U330 20001, IdeaPad U330 2267, IdeaPad U330A Lenovo IdeaPad Y330 Series IdeaPad Y330A, IdeaPad Y330G
GB-IY410	Lenovo3000 Y400 94543000 Y400 Series3000 Y410 77573000 Y410 Series3000 Y410a 77573000 Y410a Series
GB-IY430	Lenovo Ideapad Y430

Battery

GB-IY450	Lenovo IdeaPad Y450 series Lenovo IdeaPad Y450 Lenovo IdeaPad Y450 20020 Lenovo IdeaPad Y450 4189 Lenovo IdeaPad Y450A Lenovo IdeaPad Y450G
GB-IY650	IdeaPad Y650 Series
GB-IY710	Lenovo IdeaPad Y710, IdeaPad Y730, IdeaPad Y530 IdeaPad Y510
GB-IZ60T	ThinkPad Z60t 2511 ThinkPad Z60t 2512 ThinkPad Z60t 2513 ThinkPad Z60t 2514 ThinkPad Z60t Series ThinkPad Z61t 9440 ThinkPad Z61t 9441 ThinkPad Z61t 9442 ThinkPad Z61t 9443 ThinkPad Z61t 9448 ThinkPad Z61t Series
GB-IZ60TH	ThinkPad Z60t 2511 ThinkPad Z60t 2512 ThinkPad Z60t 2513 ThinkPad Z60t 2514 ThinkPad Z60t Series ThinkPad Z61t 9440 ThinkPad Z61t 9441 ThinkPad Z61t 9442 ThinkPad Z61t 9443 ThinkPad Z61t 9448 ThinkPad Z61t Series
GB-LA1	LG LG A1 Series A1 EXPRESS DUAL, A1-PB10A, A1-PP01A9, A1-PPRAG
GB-LF1	LG F1 Series F1-2224A, F1-2225A9, F1-2226A, F1-222EG, F1-2235A9, F1-2245A9, F1-224EG, F1-2255A9, F1-225EG, F1-225GY, F1-226EG, F1-227EG, F1-227GY, F1-228EG, F1-228GY, F1-22PTV, F1-2324A, F1-2325A, F1-23MMV, F1-2
GB-LK1	LG LG K1 Series K1-113PR, K1-222CR, K1-222DR, K1-222EG, K1-222PR, K1-223MA, K1-223PR, K1-223VG, K1-223WG, K1-2224A, K1-2225A8, K1-2245G, K1-2249A9, K1-225NG, K1-2333V, K1-23MXV, K1-23XPV, K1-311D
GB-LP1	LG M1 Express Dual LG M1 Pro Express Dual LG M1 Series LG P1 Express Dual LG P1 Pro Express Dual LG P1 Series LG W1 Pro Express Dual LG W1 Series LG W1-D2RLV1 LG W1-D2STV1 LG W1-J2DTV1 LG W1-J2HDV1 LG W1-J334F LG W1-JDGAG LG W1-JDGBG LG W1-KBBBV LG W1-KPC

Battery

GB-LR1	LG LG LM40 Series, LG LM50 Series, LG LM60 Series LG LM Series LE50, LM60, LM60-3B5C1, LM60-CBJA, LM60 Express, LM70, LM70 Express, LM70-QKXA LG LS Series LS45, LS55, LS55-1EFA,
GB-LR410	LG R410 R510 Series Gigabyte W476 W576 Series Gericom G.note MR0378 Series Casper TW8 Series Qaunta TW8 SW8 DW8 EAA-89 series Fujitsu Siemens SW8 TW8 Sereis
GB-LTX	LG TX Series TX EXPRESS, TX-ADGAG, TX-ADGDG, TX-ADGEG, TX-ADGFG
GG-LZ1	LG LG LW20 Series LW20-12DU1, LW20-1333, LW20-1555, LW20-1757, LW20-1777, LW20-2DDG, LW20-32DK, LW20-32DU1, LW20-3333, LW20-33MK, LW20-3555, LW20-3577, LW20-35MK, LW20-3777, LW20-72DK, LW20-72DU1, L
GB-M3420	Packard-Bell EasyNote W3420, Packard-Bell EasyNote W3281 Packard-Bell EasyNote W3420 Packard-Bell EasyNote W3450 Packard-Bell EasyNote W3540 Packard-Bell EasyNote W3840 Packard-Bell EasyNote: W1 series, W3 serien, W7 series
GB-M7521	Minote 7321, Minote 7520, Minote 7521, Minote 7521C, Minote 7521P Advent: Advent 7521 HYPERDATA: Hyperdata 7300, Hyperdata 7321 IPC PowerNote M 7321 IPC MagicNote M Series: MagicNote M 7521 IPC StarNote M Series: StarNote M
GB-M8011	Mitac MiNote 8011 and WinBook W200, W235 series

Battery

GB-M8060	<p>Mitac MiNote 8060B Mitac MiNote 8060 Mitac 8060B Mitac 8060 Gericom Hollywood Centrino 8060 Gericom Hollywood 8060 Gericom Hollywood 2040 W100 (8060B) WinBook CO</p>	WinBook COMPUTER
GB-M8066	<p>MiNote 8066 MiNote 8666 MiNote 8224 BenQ JoyBook S73, JoyBook S73G MiBook 8666 Medion MIM2090 IPC StarNote 8066 CES Note 1000, Note 2000, Note 8666</p>	
GB-M8080	<p>Mitac 8080, WinBook C100 C120 C140 C170 C220</p>	
GB-M8081	<p>Mitac: MiNote 8081, MiNote 8081P, MiNote 8381 Series Medion: MD41017, MAM2010, 8381 Series WinBook: A100, C200, C220, C225, C226, C240 Series Lenovo E255 E260 120 Cytron: MD40400</p>	
GB-M8375	<p>Mitac:8175, 8375, 8575, 8575A, 8575P Advent 7009 Other:Max, IPC, SMARTBOOK, Xerox, Issam</p>	
GB-M8399	<p>Mitac MiNote 8599 , 8399 Mitac 8599, 8399 Advent 7062, 7065 BLUEDISK Artworker M8 XP Home LION Sarasota Artworker 8599, Artworker 8399, 8599 MEDION MD42703, MD42811, MD95078, MID2030 PACKARD BELL PACKARD BELL Easy Note F7 Series</p>	
GB-M8399	<p>Mitac MiNote 8599 , 8399 Mitac 8599, 8399 Advent 7062, 7065 BLUEDISK Artworker M8 XP Home LION Sarasota Artworker 8599, Artworker 8399, 8599 MEDION MD42703, MD42811, MD95078, MID2030 PACKARD BELL PACKARD BELL Easy Note F7 Series</p>	

Battery

GB-M8630	Mitac:8630, 8640. .MD40675、 MD40776、 MD40780、 MD40790、 MD41039、 MD41050、 MD41054、 MD41060、 MD41062、 MD41131、 MD41191、 MD41272、 MD41273、 MD41274、 MD41653、 MD41983、 MD42032	Medion MD40632
GB-M8630H	Mitac:8630, 8640. .MD40675、 MD40776、 MD40780、 MD40790、 MD41039、 MD41050、 MD41054、 MD41060、 MD41062、 MD41131、 MD41191、 MD41272、 MD41273、 MD41274、 MD41653、 MD41983、 MD42032	Medion MD40632
GB-M8677	Mitac 8677 Series NEC Versa E400, Packard Bell iGo 2000, Packard Bell iGo 2410, Packard Bell iGo 2441, Packard Bell iGo 2451, Packard Bell iGo 4000, Packard Bell iGo 429 Lenovo E100 NEC NEC Versa E400 PACKARD BELL Packard Bell iGo 2000 series Packard B	
GB-M1010	MSI MS 10xx MS-1010 MS-1011 MS-1029 MS-1032 MS-1034 MS-1039 MS-10xx	
GB-MPR200	MS-1221, MS-1222, MS-1223, PR200, PR210, And PR201-Will Also Fit All Current 12" Models	
GB-MPR200H	MS-1221, MS-1222, MS-1223, PR200, PR210, And PR201-Will Also Fit All Current 12" Models	
GB-MR420	MSI VR420 PR420 PR400 MS1421 MS1422 Series NEC Versa S970 Series	
GB-MS420	MEGABOOK S420 MEGABOOK S425 MEGABOOK S430 MEGABOOK VR320 MEGABOOK VR330 MS1022 MS1024 MS-1022 MS-1024	
GB-MU100	MSI Wind U100 Notebook MSI Wind MSI Wind U100, U100X, U90 Advent Advent 4211 Medion Medion Akoya Mini E1210 LG LG X110 10" UMPC series MSI Wind 10" Mini Laptop MSI Wind NB10051 10" Display Mini Notebook (Pink) MSI Wind NB10052 10" Display Mini Notebook MS	
GB-MU100H	MSI Wind U100 Notebook	

Battery

GB-ES940	Packard Bell Easy Note A7and A8 Series NEC Versa S940 series/Lenovo Y200 series
GB-EWP22	FIC A5 A550 Gericom Genio Medion NEC E660 NEC Versa Aptitude VERSA APTITUDE J2i L320 P700 Packard Bell Easy Note SC series
GB-EWP54	VERSA M320
GB-PA28	ToughBook CF-28 seriesCF-50 seriesCF-48 series
GB-PA51	Panasonic: Panasonic Toughbook-51, Panasonic ToughBook-52 Panasonic CF Series CF-29, CF-29DC1AXS, CF-29FC1AXS, CF-29FC9AXS, CF-29JC1AXS, CF-29JC9AXS, CF-29LW1AXS, CF-51, CF-52, CF-52CCABXBM, CF-52EW1AAS, CF-52EW1AJS
GB-PAR4	Panasonic Panasonic CF-R4 Series CF-R4GC5AXS, CF-R4GW5AXR, CF-R4GW5AXS, CF-R4GWCKZBR, CF-R4GWCZZBR, CF-R4HC4AXS, CF-R4HW4AXR, CF-R4HW4AXS, CF-R4JC4AXS, CF-R4JW4AXR, CF-R4JW4AXS Panasonic CF-R5 Series CF-R5KC4AXS,
GB-PAR6	Panasonic CF-R6, CF-R7, CF-R8
GB-PAT5	CF-T4CF-T4GC5AXSCF-T4GC6AXSCF-T4GW5AXRCF-T4GW5AXSCF- T4GW6AXSCF-T4HC4AXSCF-T4HC9AXSCF-T4HW4AXRCF- T4HW4AXSCF-T4HW9AXSCF-T4HWMAXCCF-T4JWSAXRCF- T4WCBBXSCF-T5CF-T5AC1AJSCF-T5AC1AXSCF-T5AC1DJSCF- T5AC1DXSCF-T5AW1AJSCF-T5AW1AXSCF-T5AW1BJRCF- T5AW1DJSCF-T5AW1DXSCF-
GB-PAW4	CF-W4GW9HXRCF-W4GW5AXSToughbook W4CF-W4HWEZZBMCF- W4HW4AXSCF-W4GWCZZBMCF-W4GW9AXSCF-W4GC5AXSCF- W4JW8AXSCF-W4HW8HXRCF-W4HC4AXSCF-W4GWCZBM-ECCF- W4GW9AXRCF-W4CF-W4HWEZZBRCF-W4HW8AXRCF-W4GWCZZBR
GB-PAW4H	CF-W4GW9HXRCF-W4GW5AXSToughbook W4CF-W4HWEZZBMCF- W4HW4AXSCF-W4GWCZZBMCF-W4GW9AXSCF-W4GC5AXSCF- W4JW8AXSCF-W4HW8HXRCF-W4HC4AXSCF-W4GWCZBM-ECCF- W4GW9AXRCF-W4CF-W4HWEZZBRCF-W4HW8AXRCF-W4GWCZZBR

Battery

GB-PAY2	Panasonic ToughBook CF-Y2, ToughBook W2, ToughBook Y2 Panasonic CF-W2 Series CF-W2AW1AXR, CF-W2BW1AXR, CF-W2BW1HXR, CF-W2CW1AXR, CF-W2DW1AXR, CF-W2DW6AXR, CF-W2DWAZZKM, CF-W2EW1AXR, CF-W2EW6AX
GB-PAY5	Panasonic Panasonic Toughbook Y5 Panasonic CF-Y5 Series CF-Y5, CF-Y5KC2AXS, CF-Y5KW2AXS, CF-Y5KW4AXS, CF-Y5KW8AXR, CF-Y5KW8AXS, CF-Y5KWSAXP, CF-Y5KWYAXP, CF-Y5LC2AXS, CF-Y5LW2AXS, CF-Y5LW4AXS, CF-Y5LW8AXR,
GB-PW5	Panasonic CF-W5
GB-SA10	Advent 6522 Series Samsung A10 Samsung VM8000 Series Samsung VM8100 Series
GB-SADR36	SensPro 500 522 523 524 525 Series
GB-SAM50	Samsung Samsung M50 Series M50-000, M50-1730, M50-1730 Cadee, M50-1860, M50-1860 Callum, M50-2130, M50-2130 Baako, M50-T000, M50 XEH 740, M50 XEP 770 Samsung M55 Series M55-Pro T2500 Breetoo, M55-Pro T7200 Booker,
GB-SAM50H	Samsung Samsung M50 Series M50-000, M50-1730, M50-1730 Cadee, M50-1860, M50-1860 Callum, M50-2130, M50-2130 Baako, M50-T000, M50 XEH 740, M50 XEP 770 Samsung M55 Series M55-Pro T2500 Breetoo, M55-Pro T7200 Booker,
GB-SAN310	Samsung N310-KA01

Battery

GB-SANC10	Samsung NC10 10.2" All Mini Laptop series Samsung NC10-14GB Samsung NC10-14GW Samsung NC10-KA03 Samsung NC10-KA04 Samsung NC10-KA05 Samsung NC10-KA01US
GB-SANC10H	Samsung NC10 10.2" All Mini Laptop series Samsung NC10-14GB Samsung NC10-14GW Samsung NC10-KA03 Samsung NC10-KA04 Samsung NC10-KA05 Samsung NC10-KA01US
GB-SAP20	P10/P20 SERIES
GB-SAP28	Samsung Samsung V20 Series V20 cXTC 1700, V20 XTC 2000, V20 XVC 2000, V20 XVC 2400 Samsung V25 Series V25 XVC 2000c, V25 XVC 2200c, V25 XVC 2400c II, V25 XVC 2533, V25 XVC 2600c, V25 XVC 2800,
GB-SAP28H	Samsung Samsung V20 Series V20 cXTC 1700, V20 XTC 2000, V20 XVC 2000, V20 XVC 2400 Samsung V25 Series V25 XVC 2000c, V25 XVC 2200c, V25 XVC 2400c II, V25 XVC 2533, V25 XVC 2600c, V25 XVC 2801, P10/P20 Ser
GB-SAP30	Samsung Samsung P30 Series P30-004, P30-A9Y, P30-BY6, P30-CA6, P30-FT8, P30-G98, P30-HSJ, P30-KCW, P30-PD4, P30-PRC002, P30 XTC 1400, P30 XTM 1700, P30 XVC 1400, P30 XVM 1500 Samsung P35 S

Battery

GB-SAP60	Samsung Samsung NP Series NP-P50, NP-P60, NP-R40, NP-R40 Plus, NP-R45, NP-R65, NP-X60 Samsung P50 Series P50 T2400 Tytahn, P50 T2600 Tygah Samsung P50 Pro Series P50-00, P50-C003, P50-C004, P50-CV03,
GB-SAQ1	Samsung SamsungQ1 Series NP-Q1, NP-Q1-M000, NP-Q1SSD, Q1-900 Casomii, Q1-900 Ceegoo, Q1B, Q1P, Q1P SSD
GB-SAQ1EX	Samsung NP-Q1EX, Q1EX-71G (US)
GB-SAQ1H	Samsung SamsungQ1 Series NP-Q1, NP-Q1-M000, NP-Q1SSD, Q1-900 Casomii, Q1-900 Ceegoo, Q1B, Q1P, Q1P SSD
GB-SAQ1U	Q1U-ELQ1U-VQ1 UltraQ1U-Y02Q1U-XPQ1U-ELXPQ1UQ1U- A000Q1U-CMXPQ1U-SSDXPNP-Q1UQ1U-Y04Q1U-000
GB-SAQ25	Samsung NV 5000/Q10/Q20/Q25 Series
GB-SAQ25	NV5000, Q10 Series, Q10 TLC, Q10 TLC 933, Q10 TXC, Q10 TXC 1000, Q10 TXC 933, Q10 TXC 933 II, Q20 Series, Q25 1600 Byron, Q25 HXC 738, Q25 Series, Q25 TXC 1300, Q25 TXC 1400, Q25 TXC 1500, Q25 TXC 758, Q25 TXM 1500
GB-SAQ25H	Samsung NV 5000/Q10/Q20/Q25 Series
GB-SAQ30	Samsung Q30 Series,
GB-SAQ30H	Samsung Q30 Series,
GB-SAQ35	Samsung Samsung NP-Q35, Samsung NP-Q45 Samsung Q35 Series Q35-T2300 Caderu, Q35-T2300 Cotezaa, Q35 XIC 5500, Q35 XIH 2300, Q35 XIP 2300 Samsung Q35 Pro Series Q35 Pro T5500 Bitasa
GB-SAQ70	Samsung Q70, NP-Q70

Battery

GB-SAX1	Samsung Samsung NP-R20 Samsung NP-X1 Series NP-X1-1200, NP-X1-C003/SHK Samsung NP-X11 Series Samsung NT-X1 Series NT-X1-C110, NT-X1-C120 Samsung R20 Series R20, R20 XIV 5500, R20 XIV 5510
GB-SAX10	Sam Samsung Samsung X05 Series X05-000, X05-001, X05-0VU, X05-402, X05-FU2, X05-GKO, X05-L10, X05 Plus, X05 PRC001, X05-W06, X05 XTC 1400, X05 XTC 1400C, X05 XTC 1400 II, X05 XTM 1600
GB-SAX10H	Samsung Samsung X05 Series X05-000, X05-001, X05-0VU, X05-402, X05-FU2, X05-GKO, X05-L10, X05 Plus, X05 PRC001, X05-W06, X05 XTC 1400, X05 XTC 1400C, X05 XTC 1400 II, X05 XTM 1600
GB-SAX1H	Samsung Samsung NP-R20 Samsung NP-X1 Series NP-X1-1200, NP-X1-C003/SHK Samsung NP-X11 Series Samsung NT-X1 Series NT-X1-C110, NT-X1-C120 Samsung R20 Series R20, R20 XIV 5500, R20 XIV 5510 Sam

Battery

GB-SAX20	X15 X20 X25 X30 X50 M40
GB-SAX20HB	X15 X20 X25 X30 X50 M40
GB-SAX22	X22-PRO T7500 BoyarX22 WEP 7500X22 SeriesX22-A006X22-A009X22-A00BX22-Aura T7300 ChoiX22 WEB 7300X22-A001X22-A007X22-A00CX22-Aura T9300 ChoellX22 XEB 8100NP-X22X22-A005X22-A008X22-A00A
GB-SAX22H	X22-PRO T7500 BoyarX22 WEP 7500X22 SeriesX22-A006X22-A009X22-A00BX22-Aura T7300 ChoiX22 WEB 7300X22-A001X22-A007X22-A00CX22-Aura T9300 ChoellX22 XEB 8100NP-X22X22-A005X22-A008X22-A00A
BP-SBP2V	PCG-N-B90PSYA/PCG-V505/PCG-Z1/VGN-B Series
BP-SBP4V	Vaio PCG-V505/Z1 Series
BP-SBP505	Vaio PCG-X505/PCG-X505/P/PCG-X505/SP/PCG-X505CP/PCG-X505VP/PCG-X505ZP/VGN-X505VP/VGN-X505ZP
BP-SBPS3	T2/VaioVGN-TSeries
bs16	VGN- SZ55 VGN- SZ56 VGN- SZ57 VGN- SZ58 VGN- SZ59 VGN- SZ60 VGN- SZ61 VGN- SZ62 VGN- SZ63 VGN- SZ64 VGN- SZ65 VGN-CR21G VGN-CR22G VGN- AR series VGN- CR series
GB-SBP1U	Vaio PCG-U/U1/U3/U3/P
GB-SBP2E	GRX/GR1/GR2/GR3/GR5/A17GP/K76P/VGN-690/VGN-72B/G/GR100/GR200/GR300/Vaio GRX/GR3/GR5/PCG-GR7/PCG-GR9/PCG-GR90/PCG-NV/VGN-A/VGN-AS/VGN-E Series
GB-SBP2NX	PCG-GRS100/GRS700/230/GRT250/GRT270/GRT290Z/GRT750/Best/GRV600/GRX600/GRX700/GRxxx /NV100/NV200/NVxxx /Vaio PCG-GR/VGN-Kxx Series
GB-SBP2R	Vaio PCG-ELK/Vaio PCG-GRX1P/PCG-Z600LEK/Vaio PCV-P101/PCG-5316/PCG-R505/PCG-R600/PCG-Z505 Series
GB-SBP2S	Vaio PCG-SR/SR1K/SR5K/SR7K/SR9/SR17/SR17K/SR27K/SR33/SRX/SRX41P/SRX55C/SRX55TC/SRX77/SRX77P/SRX87/SRX87P/SRX99/SRX99K/SRX99P /VX Series/VX7/VX88/VX88P/VX89/VX89K/VX89K1/VX89P
GB-SBP2T	Vaio PCG-481N/PCG-TR
GB-SBP3RH	Vaio PCG-ELK/Vaio PCG-GRX1P/PCG-Z600LEK/Vaio PCV-P101/PCG-5316/PCG-R505/PCG-R600/PCG-Z505 Series
GB-SBP3T	Vaio PCG-481N/PCG-TR
GB-SBP51	Vaio PCG-161L/6C1N/C1C/C1M/C1V/C1X/505/N505/500/GT1/GT3 Series
GB-SBP51H	Vaio PCG-161L/6C1N/C1C/C1M/C1V/C1X/505/N505/500/GT1/GT3 Series
GB-SBP71	Vaio PCG 700/800/900/F/FR/FX/FXA / QR/XG/ XR
GB-SBPS1	Vaio VGN-U/VGN-U50/VGN-U70/VGN-U70P/VGN-U71/VGN-U71P/VGN-U750P
GB-SBPS10	VGN-SZ61WN/C Vaio VGN-SZ Series
GB-SBPS10H	VGN-SZ61WN/C Vaio VGN-SZ Series

Battery

GB-SBPS11	Sony VGN-TZ121 Sony VGN-TZ17/N Sony VGN-TZ28/N Sony VGN-TZ13 Sony VGN-TZ170N/B Sony VGN-TZ28N Sony VGN-TZ130N/B Sony VGN-TZ170N/N Sony VGN-TZ33/B Sony VGN-TZ131 Sony VGN-TZ17GN/B Sony VGN-TZ33/N Sony VGN-TZ132/N Sony VGN-TZ17N Sony VGN-TZ33/W Sony VGN-TZ1
GB-SBPS11H	Sony VGN-TZ121 Sony VGN-TZ17/N Sony VGN-TZ28/N Sony VGN-TZ13 Sony VGN-TZ170N/B Sony VGN-TZ28N Sony VGN-TZ130N/B Sony VGN-TZ170N/N Sony VGN-TZ33/B Sony VGN-TZ131 Sony VGN-TZ17GN/B Sony VGN-TZ33/N Sony VGN-TZ132/N Sony VGN-TZ17N Sony VGN-TZ33/W Sony VGN-TZ1
GB-SBPS12	Sony VGN-Z15, Sony VGN-Z17, Sony VGN-Z19, Sony VGN-Z25, Sony VGN-Z27, Sony VGN-Z29N, Sony VGN-Z35, Sony VGN-Z37D, Sony VGN-Z39D
GB-SBPS12H	Sony VGN-Z15, Sony VGN-Z17, Sony VGN-Z19, Sony VGN-Z25, Sony VGN-Z27, Sony VGN-Z29N, Sony VGN-Z35, Sony VGN-Z37D, Sony VGN-Z39D
GB-SBPS13	Sony Vaio VGN TX Series TX46C/B, TX46C/T, TX45C/B, TX58CN, TX57CNTX56C/B, TX56C/T, TX36C/W, TX46C/W, TX56C/WTX17C/B, TX17C/L, TX16C/B, TX28CP/L, TX27CP/BTX27CP/L, TX26C/B, TX26C/T, TX16C/W, TX15C/WTX26C/W, TX25C/W, TX38CP/L, TX37CP/BTX37CP/LTX36C/B,
GB-SBPS13H	Sony Vaio VGN TX Series TX46C/B, TX46C/T, TX45C/B, TX58CN, TX57CNTX56C/B, TX56C/T, TX36C/W, TX46C/W, TX56C/WTX17C/B, TX17C/L, TX16C/B, TX28CP/L, TX27CP/BTX27CP/L, TX26C/B, TX26C/T, TX16C/W, TX15C/WTX26C/W, TX25C/W, TX38CP/L, TX37CP/BTX37CP/LTX36C/B,
GB-SBPS14	Sony Vaio VGN-TT21JN/B, VGN-TT21M/N, VGN-TT21VN/X, VGN-TT21WN/B
GB-SBPS14H	Sony Vaio VGN-TT21JN/B, VGN-TT21M/N, VGN-TT21VN/X, VGN-TT21WN/B
GB-SBPS15	VGN-P11Z/GVGN-P11Z/QVGN-P11Z/RVGN-P13GH/QVGN-P15G/GVGN-P15G/QVGN-P15G/RVGN-P17H/GVGN-P17H/QVGN-P17H/RVGN-P19VN/QVGN-P19WN/QVGN-P31ZK/QVGN-P31ZK/RVGN-P39VL/QVGN-P45GK/NVGN-P45GK/PVGN-P45GK/QVGN-P50/GVGN-P50/RVGN-P530CH/GVGN-P530CH/QVGN-P530CH/RVGN-P530H/GV
GB-SBPS18	Sony Vaio-W series Sony W117 series Sony W127 series
GB-SBPS18H	Sony Vaio-W series Sony W117 series Sony W127 series

Battery

GB-SBPS1H	Vaio VGN-U/VGN-U50/VGN-U70/VGN-U70P/VGN-U71/VGN-U71P/VGN-U750P
GB-SBPS2	Vaio FS93G/PCG-6C1N/VFB-S1-XP/VFN-S90PSY5/AR /AR11/VGN-S/FE/FE21/FT/FS/FS515/VGN-FJ/S/S240/S260/VGN-S270/SZ/VGN-Y Series
GB-SBPS2H	Vaio FS93G/PCG-6C1N/VFB-S1-XP/VFN-S90PSY5/AR /AR11/VGN-S/FE/FE21/FT/FS/FS515/VGN-FJ/S/S240/S260/VGN-S270/SZ/VGN-Y Series
GB-SBPS2H	Vaio FS93G/PCG-6C1N/VFB-S1-XP/VFN-S90PSY5/AR /AR11/VGN-S/FE/FE21/FT/FS/FS515/VGN-FJ/S/S240/S260/VGN-S270/SZ/VGN-Y Series
GB-SBPS4	Vaio VGN-AX Series Vaio VGN-AX570G, Vaio VGN-AX580G Vaio VGN-BX Series Vaio VGN-BX143C, Vaio VGN-BX143CP, Vaio VGN-BX145CP, Vaio VGN-BX148CP, Vaio VGN-BX165CP, Vaio VGN-BX168GP, Vaio VGN-BX178CP, Vaio VGN-BX194VP, Vaio VGN-BX195EP, Vaio VGN-BX195SP, Vaio
GB-SBPS4H	Vaio VGN-AX Series Vaio VGN-AX570G, Vaio VGN-AX580G Vaio VGN-BX Series Vaio VGN-BX143C, Vaio VGN-BX143CP, Vaio VGN-BX145CP, Vaio VGN-BX148CP, Vaio VGN-BX165CP, Vaio VGN-BX168GP, Vaio VGN-BX178CP, Vaio VGN-BX194VP, Vaio VGN-BX195EP, Vaio VGN-BX195SP, Vaio
GB-SBPS5	Sony Vaio TX36TP, Sony Vaio TX37TP Sony Vaio VGN-TX Series VGN-TX15C/W, VGN-TX16C, VGN-TX16C/W, VGN-TX16GP/W, VGN-TX16LP/W, VGN-TX16SP/W, VGN-TX16TP, VGN-TX17C/B, VGN-TX17C/L, VGN-TX17GP/B, VGN-TX17GP/W, VGN-TX17TP, VGN-TX1HP, VGN-TX1HP/W, VGN-TX1XP,
GB-SBPS5H	Sony Vaio TX36TP, Sony Vaio TX37TP Sony Vaio VGN-TX Series VGN-TX15C/W, VGN-TX16C, VGN-TX16C/W, VGN-TX16GP/W, VGN-TX16LP/W, VGN-TX16SP/W, VGN-TX16TP, VGN-TX17C/B, VGN-TX17C/L, VGN-TX17GP/B, VGN-TX17GP/W, VGN-TX17TP, VGN-TX1HP, VGN-TX1HP/W, VGN-TX1XP,
GB-SBPS6	Vaio VGN-UX50 Vaio Type UX Series
GB-SBPS6H	Vaio VGN-UX50 Vaio Type UX Series
GB-SBPS7	Vaio typeG VGN-G1KBN Vaio typeG Series

Battery

GB-SBPS7H	Vaio typeG VGN-G1KBN Vaio typeG Series
GB-SBPS8	Vaio FZ18E Vaio FZ19VN Vaio FZ21E Vaio FZ29VN Vaio FZ18M Vaio FZ21M Vaio FZ11S Vaio FZ21S Vaio FZ11Z Vaio FZ21Z Vaio TYPE FZ Series
GB-SBPS8H	Vaio FZ18E Vaio FZ19VN Vaio FZ21E Vaio FZ29VN Vaio FZ18M Vaio FZ21M Vaio FZ11S Vaio FZ21S Vaio FZ11Z Vaio FZ21Z Vaio TYPE FZ Series
GB-SBPS9H	VGN- SZ55 VGN- SZ56 VGN- SZ57 VGN- SZ58 VGN- SZ59 VGN- SZ60 VGN- SZ61 VGN- SZ62 VGN- SZ63 VGN- SZ64 VGN- SZ65 VGN-CR21G VGN-CR22G VGN- AR series VGN- CR series
GB-T10H	Toshiba Toshiba Dynabook V7 Toshiba Satellite Pro Series Toshiba Satellite Pro M10, Toshiba Satellite Pro M15, Toshiba Satellite Pro 6300 Toshiba Tecra M1 Series
GB-T1100	Satellite1100/1110/ 1100-S101/1110-S153/1115-S103/1115- S123/1100-A210/1100-S153/E5/E6 series
GB-T1200	Toshiba Satellite 1200 Series Satellite 1200, Satellite 1200-S121, Satellite 1200-S122, Satellite 1200-S252 Toshiba Satellite 3000 Series Satellite 3000, Satellite 3000-100, Satellite 3000-214, Satellite 3000-400, Satellite 3000
GB-T1700	Satellite 1700/1700XCDS/1710CDS/1715XCDS/1730/1730CDT/1735XCDS/175 5/1755CDT/1755CE/1755DVD
GB-T1900	Satellite 1900 PS1901-000FS/1900/1900/1900-S305/1900 PS192C- 00UWN/1905/1905/1905-S277/1905-S301/1905-S302/1905- S303/1905-S304 Acer Aspire 1401 Acer Aspire 1403, Acer Aspire 1405 Arm Armnote CR10, AccelNote CR10, ACMA Elite 6400D Compal BR10, Freedom CR10
GB-T1950	SATELLITE 1950/1955/1955-S801/1955-S802/1955-S803/1955- S804/1955-S805/1955-S806/1955-S807

Battery

GB-T20	Libretto 20 Series Libretto 50 Series Libretto 50C T Libretto 70 Series Libretto 70C T notebook computer.
GB-T20H	Libretto 20 Series Libretto 50 Series Libretto 50C T Libretto 70 Series Libretto 70C T notebook computer.
GB-T2100	Toshiba T2100 Series- Toshiba T2100, Toshiba T2100CDS, Toshiba T2100CDT, Toshiba T2100CS, Toshiba T2100CT, Toshiba T2105CS, Toshiba T2105CT, Toshiba T2110CS, Toshiba T2110CT, Toshiba T2115CS, Toshiba T2115CT, Toshiba T2130 Series-
GB-T250	Toshiba Satellite 250/2900/4600/220/230/300/510/1400/1500/1800/2000/2100/2200/2410/2500/2600/2700/2800 Series/4000/4100/4200/4300/4400/300/4000 Series-/T2100 Series
GB-T300CT	Toshiba Portege 300CDS Toshiba Portege 300 / 4.0 CT Toshiba Portege 300CT Series Portege 300CT, Portege 305CT, Portege 310CT, Portege 315CT, Portege 320CT, Portege 325CT, Portege 330CT, Portege 335CT,
GB-T3020	Portege 3110/3020/3000CT/3110CT/3400/3410/3430/3480/3480/3480CT/3490/3490/3490CT/3440/3440/3440CT
GB-T3110	Toshiba Toshiba Portege 3110 Series Portege 3110, Portege 3110CT Toshiba Portege 3400 Series Toshiba Portege 3410 Series Portege 3410CT Toshiba Portege 3430 Series Toshiba Portege 3480 Series Portege 3480, P
GB-T3500	Toshiba Portege 3500 Series

Battery

GB-T4800	Toshiba Toshiba Satellite T1900 Series T1900, T1900C Toshiba Satellite T1910 Series T1910, T1910CS, T1910CT Toshiba Satellite T1950 Series T1950, T1950CS, T1950CT Toshiba Satellite T1960 Series T1960, T19
GB-T5200	Toshiba Satellite 5200 Series Satellite 5200, Satellite 5200-701, Satellite 5200-702, Satellite 5200-711, Satellite 5200-801, Satellite 5200-802, Satellite 5200-901, Satellite 5200-902, Satellite 5200-903, Satellite 5200-904, Sa
GB-T7000	Toshiba Toshiba Portege 7000 Series Portege 7000, Portege 7000CT Toshiba Portege 7010 Series Portege 7010CT, Portege 7010CDT Toshiba Portege 7020 Series Portege 7020CT Toshiba Portege 7140 Series Portege
GB-T7000H	Toshiba Toshiba Portege 7000 Series Portege 7000, Portege 7000CT Toshiba Portege 7010 Series Portege 7010CT, Portege 7010CDT Toshiba Portege 7020 Series Portege 7020CT Toshiba Portege 7140 Series Portege
GB-T780	Tecra 750/780 series
GB-T8000	Tecra 8000
GB-T8100	Toshiba Tecra 8100 Series Tecra 8100, Tecra 8100A, Tecra 8100B, Tecra 8100C, Tecra 8100D, Tecra 8100E, Tecra 8100F, Tecra 8100G, Tecra 8100H, Tecra 8100J, Tecra 8100K

Battery

GB-T8100H	Tecra 8100/8100A/8100B/8100C/8100D/8100E/8100F/8100G/8100H/8100J/8100K
GB-T8200	Tecra 8200
GB-T9000	Portege M100, 4000/4010 Series / Tecra 9000, 9100 Series / DynaBook S Series / Satellite 6000 Series
GB-TA10	Toshiba Toshiba Dynabook Qosmio G20/590LS, Toshiba Satellite J50 Toshiba Dynabook Satellite J60 Series Dynabook Satellite J60 146C/5, Dynabook Satellite J60 146C/5X, Dynabook Satellite J60 166D/5, Dynabook Satellite J60
GB-TA100	Toshiba Toshiba Portege A200 Toshiba Portege A100 Series Toshiba Satellite 5000 Series Satellite 5000, Satellite 5005-S504, Satellite 5005-S507 Toshiba Satellite 5005 Series Toshiba Satellite 5100 Series Sa
GB-TA135	1 Satellite A105-S361X Satellite A110-101 Satellite A110-177 Satellite A110-178 Satellite A110-203 Satellite A110-ST1111 Satellite A135-S2246 Satellite A135-S2256 Satellite A135-S2266 Satellite A135-S2276 Satellite A135-S2286 Satellite A135-S2296 Sate
GB-TA135H	1 Satellite A105-S361X Satellite A110-101 Satellite A110-177 Satellite A110-178 Satellite A110-203 Satellite A110-ST1111 Satellite A135-S2246 Satellite A135-S2256 Satellite A135-S2266 Satellite A135-S2276 Satellite A135-S2286 Satellite A135-S2296 Sate
GB-TA135H	1 Satellite A105-S361X Satellite A110-101 Satellite A110-177 Satellite A110-178 Satellite A110-203 Satellite A110-ST1111 Satellite A135-S2246 Satellite A135-S2256 Satellite A135-S2266 Satellite A135-S2276 Satellite A135-S2286 Satellite A135-S2296 Sate
GB-TA20	Satellite A20/A25/A40/A45/2450/ 2455
GB-TA200	Satellite M200, M205, A200, A205, A210, Series
GB-TA200H	Satellite M200, M205, A200, A205, A210, Series

Battery

GB-TA30	Toshiba Satellite A30-921, Toshiba Satellite Pro A30, Toshiba Satellite S2430-A620, Toshiba Satellite S2430-A740 Toshiba Satellite 2430 Series Satellite 2430-101, Satellite 2430-201, Satellite 2430-301, Satellite 2430-402, Satellite 2430-402D, Sa
GB-TA50	PORTEGE M300 PORTEGE S100 PORT?G? R200-113 QOSMIO F25- AV205/QOSMIO F25 SERIES /SATELLITE A50/ T20 SS M35 146C/2W/ M2/Tecra M3/Terca M5/ Satellite M500/ Satellite M3/Dynabook TX /M10/Dynabook SS MX/Portege M300/Portege M500 Series/Portege S100/ Satel
GB-TA50H	Toshiba Toshiba Dynabook Satellite T12, Toshiba Dynabook Satellite T20 Toshiba Dynabook Satellite T10 Series, Toshiba Dynabook Satellite T11 Series, Toshiba Dynabook Satellite T12 Series, Toshiba Dynabook TX Series, Toshib
GB-TA60	Satellite A60/A60-102/A60-106/A60-116/A60-120/A60-129/A60- 140/A60-145/A60-154/A60-174/A60-185/A60-202/A60-212/A60- 218/A60-219/A60-302/A60-332/A60-632/A60-652/A60-662/A60- 672 Satellite A60-742/A60-743/A60-752/A60-772/A60-S156/A60- S1561/A60-S159/A60-S1591/A
GB-TA60H	Satellite A60/A60-102/A60-106/A60-116/A60-120/A60-129/A60- 140/A60-145/A60-154/ A60-174/A60-185/A60-202/A60-212/A60- 218/A60-219/A60-302/A60-332/A60-632/A60-652/A60-662/A60- 672 Satellite A60-742/A60-743/A60-752/A60-772/A60-S156/A60- S1561/A60-S159/A60-S1591/A
GB-TA70	Toshiba Toshiba Satellite A70 Seires Satellite A70-S2362, Satellite A70-S249, Satellite A70-S2491, Satellite A70-S2492ST, Satellite A70-S256, Satellite A70-S2561, Satellite A70-S259, Satellite A70-S2591
GB-TA70H	Toshiba Satellit Toshiba Toshiba Satellite A70 Seires Satellite A70-S2362, Satellite A70-S249, Satellite A70-S2491, Satellite A70-S2492ST, Satellite A70-S256, Satellite A70-S2561, Satellite A70-S259, Satellite A70-S2592
GB-TA80	Toshiba Satellit Dynabook CX/45A Dynabook CX/47A Dynabook CX/855LS Dynabook CX/875LS Dynabook CX/955LS Dynabook CX/975LS Dynabook Satellite AW3 Dynabook TX/66A Dynabook TX/67A Dynabook TX/870LSFIFA Dynabook TX/880LS Dynabook TX/980LS Dynabook VX/4 Dynabook VX/5 Dynabo

Battery

GB-TA80H	Dynabook CX/45A Dynabook CX/47A Dynabook CX/855LS Dynabook CX/875LS Dynabook CX/955LS Dynabook CX/975LS Dynabook Satellite AW3 Dynabook TX/66A Dynabook TX/67A Dynabook TX/870LSFIFA Dynabook TX/880LS Dynabook TX/980LS Dynabook VX/4 Dynabook VX/5 Dynabo
GB-TA80H	Dynabook CX/45A Dynabook CX/47A Dynabook CX/855LS Dynabook CX/875LS Dynabook CX/955LS Dynabook CX/975LS Dynabook Satellite AW3 Dynabook TX/66A Dynabook TX/67A Dynabook TX/870LSFIFA Dynabook TX/880LS Dynabook TX/980LS Dynabook VX/4 Dynabook VX/5 Dynabo
GB-TE105	ToshibaSatellite E105Satellite E105-S1402Satellite E105-S1602
GB-TE205	Toshiba Satellite E200 Series, Satellite E205 Series.
GB-TF45	Qosmio F45-AV423Qosmio F45-AV411BQosmio F45 SeriesDynabook Qosmio F40/85EDynabook Qosmio F40/88EBLDynabook Qosmio F40/87DBLDynabook Qosmio F40/87CBLQosmio F40 SeriesQosmio F45-AV413Qosmio F45-AV411Dynabook Qosmio F40/86FBLDynabook Qosmio F40/86EBLDynabook
GB-TF50	Qosmio F50 Series, Qosmio F50-01U, Qosmio F50-108, Qosmio F50- 10B, Qosmio F50-10G, Qosmio F50-10K, Qosmio F50-10M, Qosmio F50-10Z, Qosmio F50-111, Qosmio F50-113, Qosmio F50-11E, Qosmio F50-11I, Qosmio F50-11J, Qosmio F50-11K, Qosmio F50- 11M, Qosmio F50-1
GB-TG30	Toshiba Toshiba Dynabook Qosmio F30 Series Dynabook Qosmio F30/83A, Dynabook Qosmio F30/85A, Dynabook Qosmio F30/87A, Dynabook Qosmio F30/87ABL, Dynabook Qosmio F30/670LS, Dynabook Qosmio F30/770LS, Dynabook Qosmio F30
GB-TG30H	Toshiba Toshiba Dynabook Qosmio F30 Series Dynabook Qosmio F30/83A, Dynabook Qosmio F30/85A, Dynabook Qosmio F30/87A, Dynabook Qosmio F30/87ABL, Dynabook Qosmio F30/670LS, Dynabook Qosmio F30/770LS, Dynabook Qosmio F30
GB-TL10	Toshiba Toshiba Equium Series Equium L20-197, Equium L20-198, Equium L20-264 Toshiba Satellite L15 Series Toshiba Satellite L25 Series Toshiba Tecra L2 Series Toshiba Satellite L10 Series Satellite L10-15

Battery

GB-TL10H	Toshiba Toshiba Equium Series Equium L20-197, Equium L20-198, Equium L20-264 Toshiba Satellite L15 Series Toshiba Satellite L25 Series Toshiba Tecra L2 Series Toshiba Satellite L10 Series Satellite L10-15
GB-TL300	Toshiba Satellite L300 Series Toshiba Satellite L305, Toshiba Satellite L311, Toshiba Satellite L312 Toshiba Satellite M300 Series Toshiba Satellite M301, Toshiba Satellite M302, Toshiba Satellite M303, Toshiba Satellite M305 Toshiba Satellite U40
GB-TL300H	Toshiba Satellite L300 Series Toshiba Satellite L305, Toshiba Satellite L311, Toshiba Satellite L312 Toshiba Satellite M300 Series Toshiba Satellite M301, Toshiba Satellite M302, Toshiba Satellite M303, Toshiba Satellite M305 Toshiba Satellite U40
GB-TL40	Equium L40 Series Equium L40-10U Equium L40-14I Satellite Pro L40 Satellite Pro L40 Series Satellite Pro L40-12Q Satellite Pro L40-12R Satellite Pro L40-12S Satellite Pro L40-12T Satellite Pro L40-135 Satellite Pro L40-14R Satellite Pro L40-15A Satell
GB-TL40H	Equium L40 Series Equium L40-10U Equium L40-14I Satellite Pro L40 Satellite Pro L40 Series Satellite Pro L40-12Q Satellite Pro L40-12R Satellite Pro L40-12S Satellite Pro L40-12T Satellite Pro L40-135 Satellite Pro L40-14R Satellite Pro L40-15A Satell
GB-TL5	L5 / 080TNL N series
GB-TL510H	Toshiba Satellite L510, Portege T130

Battery

GB-TL75	Toshiba: Toshiba Libretto 75 Series Libretto 75CT Toshiba Libretto 100 Series Libretto 100CS, Libretto 100CT Toshiba Libretto 110 Series Libretto 110, Libretto 110CST
GB-TM10	Toshiba Toshiba Dynabook V7 Toshiba Satellite Pro Series Toshiba Satellite Pro M10, Toshiba Satellite Pro M15, Toshiba Satellite Pro 6300
GB-TM18	Toshiba Tecra M1 Series
GB-TM200	M18/M19 SERIES Portege M205 / Portege M200, M400 Tablet PC, M405 Series / Satellite R10, R15 / Satellite R20, R25, Pro 6000, 6100 Series / Tecra M4, M7, TE2000, TE2100 Series
GB-TM30	Toshiba Satellite Pro M30 Toshiba Satellite M30 Series Satellite M30-100, Satellite M30-103, Satellite M30-104, Satellite M30-105, Satellite M30-106, Satellite M30-107, Satellite M30-114, Satellite M30-125,
GB-TM30H	Toshiba Satellite Pro M30 Toshiba Satellite M30 Series Satellite M30-100, Satellite M30-103, Satellite M30-104, Satellite M30-105, Satellite M30-106, Satellite M30-107, Satellite M30-114, Satellite M30-125,
GB-TM30X	Toshiba Toshiba Satellite Pro M40X-131 Toshiba Satellite M35X Series Satellite M35X-S1631 Toshiba Satellite M30X Series Satellite M30X-104, Satellite M30X-105, Satellite M30X-111, Satellite M30X-115, Sa

Battery

GB-TM30XH	Toshiba Toshiba Satellite Pro M40X-131 Toshiba Satellite M35X Series Satellite M35X-S1631 Toshiba Satellite M30X Series Satellite M30X-104, Satellite M30X-105, Satellite M30X-111, Satellite M30X-115, Sa
GB-TM60	Toshiba Toshiba Satellite M60 Series Satellite M60-132, Satellite M60-134, Satellite M60-135, Satellite M60-139, Satellite M60-161, Satellite M60-167, Satellite M60-169, Satellite M60-182, Satellite M60-183
GB-TNB100	Toshiba Netbook NB100 Toshiba Netbook NB100-01G Toshiba Netbook NB100-111 Toshiba Netbook NB100-12A Toshiba Netbook NB100-10X Toshiba Netbook NB100-11R Toshiba Netbook NB100 mini Toshiba Netbook NB100 PLL10E-00X00TEN Toshiba Netbook NB100 PLL10C-01G02U, T
GB-TNB200	Toshiba NB200 Netbook
GB-TNB200H	Toshiba NB200 Netbook
GB-TP100	Toshiba Toshiba Satellite P100-JR Toshiba Satellite P100 Series, Toshiba Satellite P105 Series Toshiba Satellite P100-100 Series Satellite P100-102, Satellite P100-103, Satellite P100-105, Satellite P100-108, Satellite
GB-TP100H	Toshiba Toshiba Satellite P100-JR Toshiba Satellite P100 Series, Toshiba Satellite P105 Series Toshiba Satellite P100-100 Series Satellite P100-102, Satellite P100-103, Satellite P100-105, Satellite P100-108, Satellite

Battery

GB-TP15	Toshiba Toshiba Satellite P10 Series Satellite P10-104, Satellite P10-133, Satellite P10-154, Satellite P10-204, Satellite P10-231, Satellite P10-251, Satellite P10-261, Satellite P10-304, Satellite P10-371, Satellite
GB-TP20	Satellite P20/P25 series
GB-TP200	Equium P200-178 Equium P200-1ED Equium P200 Series Satellite P200-10A Satellite P200-10C Satellite P200-10G Satellite P200-100 Satellite P200-10T Satellite P200-11P Satellite P200-123 Satellite P200-12D Satellite P200-12U Satellite P200-12
GB-TP200H	Equium P200-178 Equium P200-1ED Equium P200 Series Satellite P200-10A Satellite P200-10C Satellite P200-10G Satellite P200-100 Satellite P200-10T Satellite P200-11P Satellite P200-123 Satellite P200-12D Satellite P200-12U Satellite P200-12
GB-TP200H	Equium P200-178 Equium P200-1ED Equium P200 Series Satellite P200-10A Satellite P200-10C Satellite P200-10G Satellite P200-100 Satellite P200-10T Satellite P200-11P Satellite P200-123 Satellite P200-12D Satellite P200-12U Satellite P200-12
GB-TP500	Satellite P500, Satellite P500-ST5801, Satellite P500-ST6821, Satellite P500-01C,
GB-TP500H	Satellite P500, Satellite P500-ST5801, Satellite P500-ST6821, Satellite P500-01C,
GB-TR10	Tecra R10 Series
GB-TR150	R150
GB-TR200	Portege R200/R200-110/R200-S234/R200-128/R200- S2031/Dynabook SS SX/290NR, Dynabook SS SX/290NK, Dynabook SS S20 12L/2, Dynabook SS SX/190NR, Dynabook SS SX/190NK Dynabook SS S20 12L/2
GB-TR500	Toshiba Portege R500 Series
GB-TS1	Toshiba Toshiba S1 Series Toshiba Tecra S1 Series
GB-TS1H	Toshiba Toshiba S1 Series Toshiba Tecra S1 Series
GB-TU100	Libretto U100/U100-105/U100-108/U105 Series
GB-TU300	Satellite U300-ST3094Satellite U300-15QSatellite U305- S5127Satellite U300-114Satellite U300-134Satellite U305 SeriesSatellite U300 SeriesSatellite U300-13USatellite Pro U300- 15BDynabook SS M41 200E/3WSatellite U300-13KSatellite Pro U300- 14RDynabook CX/45E

Battery

GB-TU300H	Satellite U300-ST3094Satellite U300-15QSatellite U305-S5127Satellite U300-114Satellite U300-134Satellite U305 SeriesSatellite U300 SeriesSatellite U300-13USatellite Pro U300-15BDynabook SS M41 200E/3WSatellite U300-13KSatellite Pro U300-14RDynabook CX/45E
GB-TX300	Qosmio X300 Series, Qosmio X305 Series
GB-U40	FUJITSU SIEMENS -U40 U40-3S4400-G1L3, U40-3S4400-C1M1, U40-3S4400-C1H1 U40-3S4400-G1L3, U40-3S4400-C1M1, U40-3S4400-C1H1 U40-3S4000-G1B1, U40-3S4400-S1G1, U40-3S4000-S1S1 U40-3S4000-G1B1, U40-3S4400-S1G1, U40-3S4000-S1S1 Uniwill U40 Series Hasee Q213, Q22
GB-U40	FUJITSU SIEMENS -U40 U40-3S4400-G1L3, U40-3S4400-C1M1, U40-3S4400-C1H1 U40-3S4400-G1L3, U40-3S4400-C1M1, U40-3S4400-C1H1 U40-3S4000-G1B1, U40-3S4400-S1G1, U40-3S4000-S1S1 U40-3S4000-G1B1, U40-3S4400-S1G1, U40-3S4000-S1S1 Uniwill U40 Series Hasee Q213, Q22
GB-U40	FUJITSU SIEMENS -U40 U40-3S4400-G1L3, U40-3S4400-C1M1, U40-3S4400-C1H1 U40-3S4400-G1L3, U40-3S4400-C1M1, U40-3S4400-C1H1 U40-3S4000-G1B1, U40-3S4400-S1G1, U40-3S4000-S1S1 U40-3S4000-G1B1, U40-3S4400-S1G1, U40-3S4000-S1S1 Uniwill U40 Series Hasee Q213, Q22
GB-UG10	Uniwill G10 series
GB-UG11	Uniwill G11
GB-UL50	Uniwill L50 series
GB-UL51	Uniwill L50II0, L50II5, L50RI0, L51AI, L51AIx, L51II, L51IIx, L51RI, L51RIx, L53RI0, L70II0 series
GB-UN223	Uniwill Uniwill 223 Series Uniwill 223II , Uniwill 223II0 , Uniwill 223EIO Uniwill N223 Series Uniwill N223II , Uniwill N223II0 , Uniwill N223EIO Alienware Sentia 223 Series DTK DTK MaxForce 223II series Hyundai 223II series Systemax Systemax Pursuit

Battery

GB-UN245	Uniwill 245, 245ii0, 245ti0, 255, 255ti2, 259, 259ia2, 259ia2, 259ia3, 259ia7, 259ii0, 259ti2 N245, N255 N259 FUJITSU- SIEMENS Amilo A1640 , A1645 , A7640 , Ami
GB-UN245H	Uniwill 245, 245ii0, 245ti0, 255, 255ti2, 259, 259ia2, 259ia2, 259ia3, 259ia7, 259ii0, 259ti2 N245, N255 N259 FUJITSU- SIEMENS Amilo A1640 , A1645 , A7640 , Ami
GB-UN251	Advent: Advent 7016 Advent 7017 Advent 7026 Advent 7027 ERGO: Rocketbrick RocketBrick4A RocketBrick4A(N251C2) Gericom: Gericom Mobile Athlon Gericom BlockBuster XP Gericom BlockBuster Radeon M Gericom BlockBuster Advance Gericom BlockBuster
GB-UN258	Uniwill 258ka0/N258/N258AS/N258AX/N258K/N258KA0/N258SA/258SA0/N 258SA0/N258 N258SAU N258SAX ABS Mayhem G1 ACMA Elite N258KA AMAX Elite N258KA Gericom BlockBuster 2 FUJITSU-SIEMENS Amilo D-1840 , D1840 D-1845 , D1845 ; Amilo A- 1630 Widescreen , A1630 Wi
GB-UN258	Uniwill 258ka0/N258/N258AS/N258AX/N258K/N258KA0/N258SA/258SA0/N 258SA0/N258 N258SAU N258SAX ABS Mayhem G1 ACMA Elite N258KA AMAX Elite N258KA Gericom BlockBuster 2 FUJITSU-SIEMENS Amilo D-1840 , D1840 D-1845 , D1845 ; Amilo A- 1630 Widescreen , A1630 Wi

Battery

GB-UN340	Uniwill 340S1, N340S1, 340S2, N340S2, 340SX, 341C1, N341C1, 348i3 Advent 5480 Advent 2410 Advent 6412 Advent 6412DVD Advent 6413 Advent 6413A Advent 6416 Advent 6417 Altima Prestige-X Arm ArmNote 340S2 Ashton Digital MaxiMate 400 Ashton Digi
GB-UN350	IPC, Uniwill model N350 series
GB-UN351	Arm, Gericom, Hyperdata, Uniwill model N351, N355, N356 series
GB-UN35B	Advent 701270217011ERGO RocketBrick 2SGericom Per4mance XLWebshoxBellagio EvolutionWebShox 2030 XLWebshox 2SYSTEMAX Pursuit SV2/SV3Pursuit 2100Pursuit 2110Pursuit SV2PursuitSV3Uniwill N34BN35BWEBTECH Webtech N34BS1N35BS2N35 SeriesWebtech N34S8N34BS2Webtec
GB-UN755	Uniwill Uniwill N755 Series N755, N755CA5, N755IA, N755IA0, N755IA6, N755IAX, N755II, N755II0, N755II1, N755II5, N755II8, N755IIX, N755IN, N755IN0, N755INX
GB-UN755	Uniwill Uniwill N755 Series N755, N755CA5, N755IA, N755IA0, N755IA6, N755IAX, N755II, N755II0, N755II1, N755II5, N755II8, N755IIX, N755IN, N755IN0, N755INX

Battery

GB-UNM30	Uniwill M30EI0, M30EI2, M30EI, M30 Series Uniwill M31EI1, M31EI, M31E, M31 Series Averatec Notebooks: Averatec 4000 Series Averatec 4100 series Averatec 4100AH 4100EH Averatec 4155 4155AH 4155EH 4155EH1 Averatec 4200 4200EH 4215 4215EH Averatec 4260 426
GB-W62	Haier W62 W62G EM-400L2S battery
GB-WJ1	ECS, GreenNote G320, G720, G799 and WinBook J1 series
GB-WJ4	WinBook J4 Advent 7060 Advent 7073 ECS Green G700 EM-420C10S EM-420C9 EM-G730L2 EMC31J LIPX036
GB-WJ4H	WinBook J4 Advent 7060 Advent 7073 ECS Green G700 EM-420C10S EM-420C9 EM-G730L2 EMC31J LIPX036
GB-WX1	WinBook - X family Laptop X1 Series, X2 Series